



---

# Quantum

## User Manual

AB-V-MA-00641\_RevA14  
08 July 2025

# Contents

<b>1 Introduction</b>	<b>4</b>
1.1 Scope	5
1.2 Terms and abbreviations	6
1.3 Document conventions	9
1.4 Disclaimer	10
<b>2 Installation</b>	<b>11</b>
2.1 PC Minimum Requirements	11
2.2 Software installation procedure	11
<b>3 Settings</b>	<b>15</b>
3.1 System Configuration	15
3.2 Quantum Management	24
3.3 Receiver Management	33
3.4 System Status	58
3.5 Authorisations	60
3.6 Display	65
3.7 Notifications	72
3.8 Screensaver	73
3.9 Close Quantum	76
<b>4 Screen overview</b>	<b>77</b>
4.1 Sidebar	77
4.2 Main Display Screen	81
4.3 Date and time	81
4.4 Menu icon	81
4.5 Display Tabs	81
4.6 Notification Tab	81
4.7 Screensaver	84
<b>5 Display configuration</b>	<b>85</b>
5.1 Tab configuration	85
5.2 User-configurable tile layouts	87
<b>6 Views</b>	<b>91</b>
6.1 Selecting views	91
6.2 Correction View - Descriptions	94
6.3 GNSS Status View - Descriptions	102
6.4 Solutions View - Descriptions	111


6.5 Heading and INS View - Descriptions .....	115
6.6 Interference and Spoofing View - Descriptions .....	120
6.7 Tides View – Descriptions .....	127
6.8 System Status View .....	130
<b>7 Troubleshooting .....</b>	<b>131</b>
<b>8 Reference information .....</b>	<b>136</b>
8.1 Tides formats .....	136
8.2 Heading formats .....	139
8.3 Alert management sentence formats .....	140
<b>9 Contact information .....</b>	<b>143</b>
9.1 Veripos Support details .....	143
<b>10 Appendix .....</b>	<b>144</b>
10.1 Veripos PPP station ID's .....	144
10.2 Veripos reference stations .....	144
10.3 L-band coverage map .....	145

# 1 Introduction

Quantum is the latest visualisation software released by Hexagon | Veripos. It is designed to clearly display the most relevant information required for both DP and Survey operations.

Quantum is a quality, position and heading monitoring software package with a configurable graphical user interface. Vessels may customise displays to match specific end-user requirements and preferences. The views available in Quantum range from high-level, appropriate for standard operations, to detailed views for specific operating scenarios or troubleshooting. Users not requiring a custom configuration can select from predefined default page layouts.

This manual will focus on Quantum PC use in conjunction with the LD8 and LD900 Veripos receivers.



Quantum software layout example



## 1.1 Scope

This manual covers the following aspects of Quantum for Microsoft Windows 7 or later:

- Installation
- Interfacing to compatible Veripos receivers
- Software configuration
- Operational procedures
- Receiver configuration

### 1.1.1 Contents

Chapter	Contents
Introduction	Specifies the purpose of this manual, provides an overview of the Quantum software and explains the document conventions used.
Installation	Describes the software installation process, minimum PC specifications and Veripos receiver compatibility.
Settings	Describes the Quantum settings menu in detail.
Screen overview	Describes the Quantum screen layout in detail.
Display Configuration	Explains the configurable display options such as adding and removing display tabs and configuring display tiles.
Views	Describes all available view options in detail.
Troubleshooting	Provides basic fault-finding advice and examples of possible error states.
Reference information	Provides technical specifications.
Contact information	Contains contact information for the Veripos Helpdesk.
Appendix	Provides additional supplementary material.

## 1.2 Terms and abbreviations

ACN	Alert Control Input - Input to acknowledge or query alert status
ALC	Alert List Cyclic - Active alerts & revision status
ALF	Alert List Flag - Output of alert priority, state, & type
APEX	Veripos high accuracy positioning solution
ApexTide	Tide correction sources derived from Veripos PPP solutions
Baud	Unit of symbol transmission rate; typically bits per second in binary systems
BEIDOU	Chinese commissioned GNSS
BESTPOS / BESTGPSPOS	GNSS output message with position and quality
CAM	Central Alert Management
COG	Course over Ground
CMR	GNSS correction format
COM	Communication Port
dB	Decibel
DGPS	Differential Global Positioning System
DHCP	Dynamic Host Configuration Protocol
DOP	Dilution of Precision
DP	Dynamic Positioning
DQI	Differential Quality Indicator
EGM96	Earth Gravitational Model 1996
EGM08	Earth Gravitational Model 2008
GALILEO	European commissioned GNSS
GGA	Global Positioning System Fix Data - Fix data including 3D position & accuracy
GLL	Geographic Position - Latitude & longitude of the position fix.
GLONASS	GLOBAL NAVIGATION Satellite System - Russian commissioned GNSS
GNSS	Global Navigation Satellite System
GP	GPS talker ID prefix used in NMEA 0183 sentence types (e.g., GPGGA)
GPS	Global Positioning System - United States commissioned GNSS
GRIT	Veripos GNSS interference & spoofing detection module
GRS	GNSS Range Residuals - Difference between measured & expected satellite ranges
GSA	GNSS DOP and Active Satellites – Used satellites & DOP values
GSV	GNSS Pseudorange Error Statistics - Error estimates for position fi
HDG	Heading (True)
HDT	True heading derived from external sensors
HDOP	Horizontal Dilution of Precision
Hz	Hertz
IALA	International Association of Marine Aids to Navigation and Lighthouse Authorities
ID	Identification

INS	Inertial Navigation System
INHDT	INS-derived heading in NMEA format
INSPVA	INS Position, Velocity, and Attitude sentence
IMCA	International Marine Contractors Association
IMU	Inertial Measurement Unit
IP	Internet Protocol
IPv4	Internet Protocol Version 4
LAN	Local Area Network
L-band	Signal transmitted to carry correction data to mobile users
LED	Light Emitting Diode
NMEA	National Marine Electronics Association
NTRIP	Networked Transport of RTCM via Internet Protocol
MSS	Mean Sea Surface
PASHR	Proprietary Attitude Sentence, Heading, & Rate
PDOP	Positional Dilution of Precision
PPP	Precise Point Positioning
PPP-AR	Precise Point Positioning-Ambiguity Resolution
PPS	Pulse Per Second
PRN	Pseudo Random Noise
PSN	Product Serial Number
PTP	Precision Time Protocol
RAIM	Receiver Autonomous Integrity Monitoring
RS232	Recommended Standard 232
RS422	Recommended Standard 422
RTCM	Radio Technical Commission for Maritime Services
RTCMv2 / RTCMv3	GNSS correction formats
RTK	Real-Time Kinematic
SAL	Service Access License
SBAS	Satellite Based Augmentation System
SD	Standard Deviation
SOG	Speed over Ground
Standard	Veripos single-frequency DGPS correction service providing entry-level accuracy
TCP	Transmission Control Protocol
THS	NMEA sentence for true heading and speed
TRINAV	NMEA-style output sentence
UDP	User Datagram Protocol
UI	User Interface
UKOOA	Industry-standard NMEA-style sentence format used offshore
Ultra	Veripos high accuracy position solution

UltraTide	Tide correction sources derived from Veripos PPP solutions
USB	Universal Serial Bus
UTC	Coordinated Universal Time
VDOP	Vertical Dilution of Precision
VTG	Course and Ground Speed - Course (true/magnetic) & speed over ground
Wi-Fi	IEEE 802.11 (wireless) standard
ZDA	Time and Date – Supplies UTC time, day, month, year, & local time zone offset

## 1.3 Document conventions

### 1.3.1 Typographical conventions

*Italic* or **bold** text is used to emphasize certain information. *Italic* is also used in cross-references to other parts of the document and to other documents.

**Bold** text is also used for indicators and touch screen “push-buttons” commands.

[Blue](#) text is used for hyperlinking to other sections within this document or to external documents or websites.

***Bold italic*** text is used when display screens are mentioned in text.

`Monospace` text is used for input/output strings to/from the device.

### 1.3.2 Special Notices



#### **WARNING**

A warning indicates the risk of bodily harm or serious damage to the hardware.



#### **CAUTION**

A caution indicates the risk of damaging the hardware or adversely impacting the operation of the system.



#### **NOTE**

A note contains important information to help you make better use of the system.

## 1.4 Disclaimer

### Hexagon Autonomous Solutions division proprietary data

This document and the information contained herein are the exclusive properties of Veripos Limited, and/or their affiliates within the Autonomous Solutions division of the Hexagon AB group of companies ("Hexagon").

No part of this document may be reproduced, displayed, distributed, or used in any medium, in connection with any other materials, or for any purpose without prior written permission from Hexagon. Applications for permission may be directed to [contact.ap@hexagon.com](mailto:contact.ap@hexagon.com). Unauthorized reproduction, display, distribution or use may result in civil as well as criminal sanctions under the applicable laws. Hexagon aggressively protects and enforces its intellectual property rights to the fullest extent allowed by law.

This document and the information contained herein are provided AS IS and without any representation or warranty of any kind. Hexagon disclaims all warranties, express or implied, including but not limited to any warranties of merchantability, non-infringement, and fitness for a particular purpose. Nothing herein constitutes a binding obligation on Hexagon.

The information contained herein is subject to change without notice.

© **Copyright 2025** Hexagon AB and/or its subsidiaries and affiliates. All rights reserved.

## 2 Installation

Quantum is available for download from the Veripos support site <https://help.veripos.com>.

### 2.1 PC Minimum Requirements

The operating systems currently supported by Quantum are Windows 7 or later (64bit).

The minimum specifications for running Quantum software are:

Processor:	i5 (2nd generation or later) @ 3.2GHz
Memory:	3 GB RAM
Hard disk:	250 GB
Serial ports:	Optional for Tides data output and serial gyro input
Ethernet:	10/100 Mbps
Display:	17", 1280 x 1024 minimum resolution
Peripherals:	Mouse & keyboard
Operating system:	Windows 7 or later (64-bit)

Veripos can supply PC hardware with the correct specifications to ensure compatibility.

### 2.2 Software installation procedure

Detailed below is the procedure for installing Quantum software on a PC.




#### NOTE

Uninstall any other previous versions of Quantum that already exist on the PC prior to the installation of the latest version of Quantum.


#### 2.2.1 Installing Quantum on a PC

Double-click the Quantum installer file (the version number may differ from the example below):




*Quantum installer file*

Running the installation files will launch the setup wizard. Click **Next >** to proceed with the installation:



*Quantum Setup Wizard – Initial page*


Please review and, if satisfied, agree to the license agreement, then click **Next >**:



*'License Agreement' page*




Select the folder where you wish to install the Quantum software or leave the setting as the default directory and click **Next >**:




*Installation directory*

If desired, tick the **Create Quantum Graphics Desktop Icon** option, making it more straightforward to launch the software by using a desktop icon:




*Additional installation options*

Quantum is now ready to install. Click **Install** to continue:



*Ready to Install' page*

A confirmation will appear upon completion of installation. Select the two checkboxes based on preference and complete the installation by clicking **Finish**:



*Quantum Setup Wizard – Completion*

Users may launch Quantum via the desktop shortcut or the Windows Start Menu (**Start > All Programs > Veripos > Quantum > Run Quantum**).


## 3 Settings

### 3.1 System Configuration

Users launching Quantum on a PC for the first time will need to create an initial configuration. The section **Importing configurations** covers the import of previous configurations. Note that users should only import configurations from version 6 or later.

#### 3.1.1 Creating a new configuration

Quantum can locally save up to four separate configurations. To create a new configuration, click any of the four tiles as shown below:



*'System Configuration' page – First time run*

#### 3.1.2 Receiver configuration

Specify the Receiver Type and enter the Receiver IP address assigned to the unit. Clicking on any of the Receiver IP address fields will activate the on-screen keypad:



After entering details, click **Next**.

The next page will list the Quantum licensing options currently associated with the active license or prompt the user to enter a new license as below:



*'New Configuration Licensing' page*

If a new Quantum licence code is required, contact Veripos Support for assistance. For further information regarding Quantum licence codes, please refer to the [Quantum - Software licenses](#) section.

Upon receiving a licence code from support, enter the code and click **Next**.


### 3.1.3 Save and launch configuration

Prior to saving, users must name the configuration. It is good practice to create an informative name for a configuration, such as the vessel name and the date or the name of a specific project:



*'Config Name' page*


Users may then save the configuration by selecting either the **Save & Launch** or **Save & Manage** options. Save and Launch will start the configuration. Save and Manage will open the **System Configuration** menu, allowing for more changes, if necessary, before the configuration launch:



*Save configuration options*

### 3.1.4 Dashboard layout – First-time run


Upon starting a configuration, a user will be prompted by the display below, with options to choose either **Load Preset Layout** or **Start with Blank Layout**. Selecting the **Load Preset Layout** option will launch a predefined tile layout. Selecting **Start with Blank Layout** will require manual configuration of tiles:



*Dashboard layout option*

### 3.1.5 System Configuration – After initial setup

Quantum provides both a day mode (default) and a night mode. A moon icon located at the top left of the screen allows for switching between the two. Note that this manual will use night mode for screen examples.



Quantum menu icon and day/night mode toggle

The **System Configuration** menu is available after the initial setup is complete. To access the Quantum System Configuration menu, select the **menu** (☰) icon located at the top left of the screen.

Select the **Settings** icon:



Quantum Settings icon

Selecting the Settings icon will present the **Settings** page.

As shown below, basic system information is available on the Settings page (configuration name, unit ID, unit type, and IP address):



*Settings main page – Quantum DP*

Below the system information, the **System Configuration** menu item allows for Quantum configuration setup and editing:




*System Configuration menu*

Clicking on the above will reveal two Settings sub-sections (Quantum Management and Receiver Management) and display any (active and inactive) configurations that users can export, edit, or launch.

### 3.1.6 Exporting configurations


Upon creating a configuration, it is possible to export it to a file, providing the ability to back up configurations, which can be imported back into Quantum later if required.

From the System Configuration menu, click **Export** on the desired configuration:



*Export configuration option (LD8)*

Choose a location to save the configuration file (e.g. PC hard drive or external USB storage), then select **Export Configuration** to save the configuration:




*Save exported Quantum config file*



### 3.1.7 Importing configurations

To import a Quantum configuration, go to **Settings > System Configuration** and click **Import Configuration**:




*Import Configuration option*

Browse to the required Quantum file and then click **Import Configuration**:



*Import Configuration – Browsing to*


Upon display of the imported configuration, click **Start** to activate it:



*Start imported configuration*


### 3.1.8 Deleting configurations

To delete a Quantum configuration, go to **Settings > System Configuration** and click **Delete**:



*Delete configuration*

A warning message will be displayed. Press **OK** to delete the configuration:



*Delete configuration confirmation*




#### NOTE

It is impossible to delete Active configurations.

### 3.1.9 Editing configurations

To edit a Quantum configuration, go to **Settings > System Configuration** and click **Edit**:




*Edit configuration*

Edit allows changes to configuration parameters, e.g., the connection IP address or configuration name. After editing the configuration, select the **Save & Launch** or **Save & Manage** configuration option.

When editing the active configuration, select the **Save & Launch** option to apply any new settings.




## 3.2 Quantum Management

While in the System Configuration menu, clicking on **System Configuration** will allow access to the Quantum Management sub-menu:




Clicking **Quantum Management** provides the ability to configure **Tides**, **Heading Display** and **PC Port Configuration**.


The Quantum Management - Overview page will show Tides and Heading Display in one of three states:

 <b>Configured</b>	Configuration carried out and applied
 <b>Not Configured</b>	Not yet configured or not active
 <b>Unlicensed</b>	Not yet licensed, contact Veripos Support to license if required

To edit Quantum Management configurations, select **Edit**, located at the bottom right-hand corner of the Quantum Management - Overview screen:




Each menu is separated by tabs, with a highlighted background indicating which menu is presently selected. Upon clicking **ENABLED**, additional configuration options will appear.



### 3.2.1 Tides

#### Enabling Tides

Upon first access, Tides will be DISABLED, and no other options will be available. Toggling DISABLED to **ENABLED** will allow for the configuration of Tides options. Use **Apply** to save any changes made.



*Tides configuration*

## Logging

This will display the Tides file save path, where both Sprint and Tidesinfo files are generated. Removing files from this location will restart the Doodson Tides calculation, but copying files will not impact it.

### Settings > Antenna Height

Users can enter the Antenna height above the waterline (in metres) here. When using the Geoid Tide, this value is required to be updated regularly with vessel draft changes. MSS Tide does not use the antenna height.

### Settings > Averaging Period

The averaging period is the interval time which calculates each tide value. This sliding scale allows for the specification of tide value calculation interval in minutes, from 1 to 60.


### Settings > Geoid Model

This allows for the selection of Geoidal Model EGM96, EGM08 or USER, a change which will only apply to Geoid Tide. When selecting USER, the option to enter a Geoid separation value (metres) will appear. This Geoid Model selection is not applicable for any position output.

### Output > Output Format

The system can output Tide information in two different formats TIDEINFO, or SPRINT. The details of these formats are available in the Reference information section.


By default, the output format is **DISABLED**:



*Tides output*

### Output > Output Format > TIDEINFO / SPRINT > Output Rate


Toggleing Output Rate to either **TIDEINFO** or **SPRINT** will reveal the option to configure Output Rate, which users can toggle between **ON CHANGE** and **1HZ**. ON CHANGE will only output one epoch at the end of the averaging period, whereas 1HZ will output an epoch every second with a new timestamp.



*Output Rate*

### Output > Output Format > TIDEINFO / SPRINT > Output Type


The Tides output message can be outputted from the PC using **TCP/IP** and **Serial**. When users select either option (or both), additional configuration options will appear.



*Output Type*

### Output > Output Format > TIDEINFO / SPRINT > Output Type > TCP/IP Port

When selecting TCP/IP, a port within the range of 9900-9999 should be specified:



*TCP/IP Port*

### Output > Output Format > TIDEINFO / SPRINT > Output Type > SERIAL

When selecting the **SERIAL** output type, several additional options will appear:



*Serial Port*

### Output > Output Format > TIDEINFO / SPRINT > Output Type > SERIAL > Serial Port

A sliding scale will allow the selection of the desired serial port from which to output.

### Output > Output Format > TIDEINFO / SPRINT > Output Type > SERIAL > Baud Rate

Baud **1200, 2400, 4800, 9600, 19200, 38400, 57600** or **115200** is available.

### Output > Output Format > TIDEINFO / SPRINT > Output Type > SERIAL > Protocol

Where available on rackmount solutions Protocol can be set to **RS232** or **RS422**.

### Output > Output Format > TIDEINFO / SPRINT > Output Type > SERIAL > Stop Bits

The Stop Bits can be set to **1** or **2**.

### Output > Output Format > TIDEINFO / SPRINT > Output Type > SERIAL > Data Bits


The Data Bits can be set to **7** or **8**.

### Output > Output Format > TIDEINFO / SPRINT > Output Type > SERIAL > Parity Bits

The Parity Bits can be set to **NONE**, **ODD** or **EVEN**.

## Calculation

Users have the option to **Restart Tides Calculation**, which will reset the MSS Tides and require the system to accumulate 39 hours of data before the tides information becomes available. For Geoid Tides users, the tides information will be available immediately after the initial averaging period is completed.



### CAUTION

MSS Tides will take 39 hours to initialise after a reset

## 3.2.2 Heading Display

Upon first access, the Heading Display will be DISABLED, and no options will be present. Toggling DISABLED to **ENABLED** will allow for the configuration of Heading Display options. Use **Apply** to save any changes made.

### Heading Display > Source

When toggled to GNSS, no further configuration is necessary. Toggling to EXTERNAL will allow for an external source of [NMEA format](#) heading to be input to Quantum for display purposes, and it will also display additional options as detailed below:



### NOTE

When GNSS Heading is the selected source, users must also enable Heading in the LD8 or LD900 receiver

### Heading Display > Offset


This option will appear when Heading Output is ENABLED, and users can set it to a value between -180° and 180°. This option allows for the application of an offset to the calculation. Any offset value entered in here will only change the heading display and won't change the heading output.





### Heading Display > Source > EXTERNAL > Input Type > TCP/IP

Toggling Input Type to TCP/IP will present additional configuration options:



The screenshot shows the 'Heading Display' configuration screen. The 'Source' is set to 'EXTERNAL'. The 'Input Type' is set to 'TCP/IP'. Below 'Input Type', there are four input fields for the IP address (each with a default value of 192.168.1.1) and a single input field for the TCP/IP port (with a default value of 80). A note at the bottom indicates 'Valid Range: 1-9999'.

*TCP/IP configuration*

### Heading Display > Source > EXTERNAL > Input Type > TCP/IP > IP Address


Clicking within any of the fields will bring up the onscreen keyboard, allowing the input of an IP Address

### Heading Display > Source > EXTERNAL > Input Type > TCP/IP > TCP

Allows the entry of a TCP/IP port number between 1-9999

### Heading Display > Source > EXTERNAL > Input Type > SERIAL

Toggling Input Type to SERIAL will present additional configuration options as detailed below:



The screenshot shows the 'Heading Display' configuration screen. The 'Source' is set to 'EXTERNAL'. The 'Input Type' is set to 'SERIAL'. Below 'Input Type', there are several configuration options: 'Serial Port' (set to COM1), 'Baud Rate' (set to 9600), 'Protocol' (set to RS232), 'Stop Bits' (set to 1), 'Bitrate' (set to 7), 'Parity Bits' (set to NONE), and 'Offset' (set to 0). A note at the bottom indicates 'Will only affect display'.

*Heading Display - Serial configuration*

**Heading Display > Source > EXTERNAL > Input Type > SERIAL > Serial Port**

Allows the selection of a PC Serial port.

**Heading Display > Source > EXTERNAL > Input Type > SERIAL > Baud Rate**

The baud rates available for selection are **1200, 2400, 4800, 9600, 19200, 38400, 57600** or **115200**.

**Heading Display > Source > EXTERNAL > Input Type > SERIAL > Protocol**

Where available on rackmount solutions Protocol can be set to **RS232** or **RS422**.

**Heading Display > Source > EXTERNAL > Input Type > SERIAL > Stop Bits**

Allows the selection of **1** or **2** Stop Bits.

**Heading Display > Source > EXTERNAL > Input Type > SERIAL > Bit Rate**

Allows the selection of **7** or **8** Bitrate.

**Heading Display > Source > EXTERNAL > Input Type > SERIAL > Parity Bits**

Allows the selection of **NONE**, **ODD** or **EVEN** Parity Bits.

**Heading Display > Source > EXTERNAL > Input Type > SERIAL > Offset**

Allows the input of a display offset.


### 3.2.3 PC Port Configuration

Within PC Port Configuration, users can toggle available port functionality from NONE to **BAM** (Bridge Alert Management) or where connected to a MOXA PC, **ICOM BRIDGE**.

#### 3.2.3.1 BAM

BAM provides the ability to configure available PC Serial ports for bridge alert message transmission and reception with a Central Alert Management (CAM) system, using proprietary Veripos (non-EC 61162-1 / NMEA 0183 compliant) **ALC**, **ALF** and **ACN** messages.

A Cyclic Alert List (ALC) message sent every 30 seconds details current alerts and the detection of jamming or spoofing events triggers the transmission of an Alert (ALF) sentence. Alert Commands (ACN), sent from a CAM system to Quantum, will acknowledge receipt of or request retransmission of ALF sentences.



#### NOTE

BAM can only be configured on one port at a time and is unavailable on ports already used for Tides or Heading Display

#### PC Port Configuration > COM# / NMEA# > Function > BAM > Baud Rate

Baud **1200**, **2400**, **4800**, **9600**, **19200**, **38400**, **57600** or **115200** is available.

#### PC Port Configuration > COM# / NMEA# > Function > BAM > Stop Bits

Allows the selection of **1** or **2** Stop Bits.

#### PC Port Configuration > COM# / NMEA# > Function > BAM > Parity Bits


Allows the selection of **NONE**, **ODD** or **EVEN** Parity Bits.

#### PC Port Configuration > COM# / NMEA# > Function > BAM > Data Bits

Allows the selection of **7**, or **8** Data Bits.

### 3.2.3.2 ICOM BRIDGE

Rackmount MOXA PC Quantum installations bridge LD900 ICOM port 1-4 outputs to a MOXA PC's NMEA 1-4 ports. Upon configuration of the ICOM ports, as detailed below, the bridge will initialise.



The screenshot shows the 'PC Port Configuration' tab with sub-tabs for COM1, COM2, NMEA1, NMEA2, NMEA3, and NMEA4. The NMEA1 sub-tab is active, showing the following settings:

- Function:** Radio buttons for NONE, BAM, and ICOM BRIDGE (selected).
- Baud rate:** A slider set to 38400.
- Stop Bits:** Radio buttons for 1 (selected) and 2.
- Parity Bits:** Radio buttons for NONE (selected), ODD, and EVEN.
- Data Bits:** Radio buttons for 7 and 8 (selected).



#### NOTE

ICOM Bridging requires LAN1 to be on the same network as the MOXA PC.

The NMEA to ICOM BRIDGE correspondence is as follows:

NMEA1 - ICOM1 (TCP port 3001)  
 NMEA2 - ICOM2 (TCP port 3002)  
 NMEA3 - ICOM3 (TCP port 3003)  
 NMEA4 - ICOM4 (TCP port 3004)

NMEA ports are RS422 only, and the following format applies:

NMEA TXA = TX-  
 NMEA TXB = Tx+  
 NMEA RX A = Rx-  
 NMEA RXB = Rx+

**PC Port Configuration > COM# / NMEA# > Function > ICOM BRIDGE > Baud Rate**

Baud **1200, 2400, 4800, 9600, 19200, 38400, 57600** or **115200** is available.

**PC Port Configuration > COM# / NMEA# > Function > ICOM BRIDGE> Stop Bits**

Allows the selection of **1** or **2** Stop Bits.

**PC Port Configuration > COM# / NMEA# > Function > ICOM BRIDGE> Parity Bits**


Allows the selection of **NONE**, **ODD** or **EVEN** Parity Bits.

**PC Port Configuration > COM# / NMEA# > Function > ICOM BRIDGE> Data Bits**


Allows the selection of **7**, or **8** Data Bits.

### 3.3 Receiver Management

Clicking on **System Configuration** will allow access to the **Receiver Management - Overview** sub-menu, which provides an overview of the current receiver configuration. Clicking **Edit** will display the configurable options for the receiver.




Clicking **Receiver Actions**, located at the bottom-left of the Receiver Management page, will allow access to the receiver configurable options as detailed in the next section:



### 3.3.1 Receiver Actions

Receiver actions provide the ability to factory reset and reboot the receiver or modify network settings:



#### Factory Reset

A factory reset will cause the receiver to revert to factory default settings, with the exception of IP Address. Users should only perform a factory reset under the advice of Veripos Support.



#### NOTE

To delete the all logged files please reference the `FILEDELETE` command found in the [LD8 Installation and Operations Manual](#).

#### Reboot

Reboot reboots the unit, resets any active positioning, and causes active PPP solutions to re-converge.

#### Network

The Network option allows for both LAN configuration and also allows the receiver to use its GPS time to synchronise the clocks on other network equipment.

#### Network > IP Config (LD8) / Network > LAN1 (LD900)




#### CAUTION

Entering an incorrect IP address will cause Quantum to stop functioning.

Users can set the **Mode** to **DISABLED**, **DHCP** or **STATIC**, where the **IP Address**, **Subnet Mask** and **Gateway IP** must be defined. **DNS** is available as a configurable option if required:




Network > IP Config (LD8)



Network > LAN1 (LD900)

### Network (LD900) > LAN2

The LD900 MMI controls LAN2 network settings, and the information available here is for reference only.



*LAN2 configuration*

### Network (LD900) > Wi-Fi


Wi-Fi options should be left DISABLED as the LD900 presently has no Wi-Fi functionality.



*Wi-Fi settings*


### Network > PTP

By default, PTP Mode is set to DISABLED. However, when toggling PTP Mode to ENABLED, the receiver can use GPS time to synchronise the clocks on other network equipment.



*Default PTP Mode (LD8 example)*

After toggling PTP Mode to ENABLED, additional Time Scale and Profile options will appear:




*PTP Mode toggled to Enabled (LD8 example)*


Users can toggle **Time Scale** between **PTP** format (default), which does not correct for leap seconds, or **UTC** format, which corrects for leap seconds and can set **Profile** to the default of **UDP E2E** (end to end), **UDP P2P** (peer to peer), **ETH E2E** (end to end), **ETH P2P** (peer to peer) or **ITU-T**.

### 3.3.2 Receiver Management – Edit

Within the Receiver Management - Edit page component menus are tab separated, with a highlighted background indicating which menu tab is selected. As shown in the examples below, the tabs available will depend on authorised features and the product in use:




*LD8 & LD900 Receiver Management, with authorised Heading*



*LD900 Receiver Management, with authorised INS (and) Heading*

#### 3.3.2.1 Position



#### PPP > GNSS1 Mode / GNSS2 Mode

Veripos APEX and Ultra PPP provide worldwide decimetre accuracy positioning with no range limitations. On systems with corrections subscriptions that include both Ultra and Apex, Veripos recommend that users set Mode to **AUTO** to allow the receiver to select the solution with the best standard deviation automatically.



#### NOTE

**Secondary Positioning is only available for Authorised LD900 systems.**

- The activation code applies to both primary and secondary solutions.
- The secondary positioning mode does not support APEX Pro and will default to





APEX5 when activated for APEX Pro.

- The secondary positioning solution NMEA position output is limited to 1Hz and COM4 and COM5 only (ICOM ports are unavailable).
- IALA, 3rd Party, and RTK corrections are unavailable for secondary positioning.



### CAUTION

If using only Apex or Ultra corrections users should ensure that the Mode selected matches the service activated by the Helpdesk.

### NMEA Config > NMEA DQI

When using either Apex or Ultra PPP services the NMEA DQI is a value reported within NMEA GGA messages to indicate a converged PPP solution status. This value can be toggled between either 2 or 5. When set to 2 and the system has corrections applied to the position, a 2 will be output. When set to 5 and a PPP solution is fully converged the DQI value will be 5.

### NMEA Config > NMEA Precision

It is possible to configure the number of decimal places used in the Latitude and Longitude fields output in the GGA Message. The precision can be set to 5, 6, 7 or 8.

### NMEA Config > NMEA Talker

The ability to interface with legacy hardware is provided. The NMEA Talker can be toggled between Auto and GP.

### TRINAV Config > Output Format

The ability to toggle TRINAV Output Format between V3 and V4 is provided.

### TRINAV Config > NavPoint Number

The ability to enter a NavPoint Number is provided.

### RAIM > RAIM Mode


Receiver autonomous integrity monitoring (RAIM) is a technology developed to assess the integrity of GNSS signals used by a GNSS receiver. RAIM uses redundant signals and a statistical function to determine if there are problems with the positioning solution; in simple terms, RAIM acts as an internal self-check. RAIM is enabled by default. Do not disable RAIM unless advised by Customer Support.



### NOTE

The configuration parameters for NMEA Config and RAIM will be applied to both primary and secondary position solutions.

### 3.3.2.2 GNSS



Receiver Management – GNSS (LD900 example)

#### GNSS Config > Tracking Elevation Mask

The Tracking Elevation Mask prevents GNSS satellites on or below a certain elevation from being tracked. Veripos recommends the default value of 10 degrees for optimal performance.

#### GNSS Config > Signal Tracking



#### CAUTION

Do not change the default signal tracking unless advised by Veripos Support.



#### NOTE

Users can not turn off constellations selected as the primary time source.

Specific GNSS constellations or particular constellation signals may be toggled **On** or **Off**.

#### GNSS Config > Time Source

Time Source allows users to specify GPS, BEIDOU, or GALILEO as the primary timing source.

#### PPS Settings > PPS Control

The PPS functionality can be DISABLED and ENABLED.


#### PPS Settings > PPS Polarity

The PPS Polarity can be switched between POSITIVE and NEGATIVE.

#### PPS Settings > PPS Pulse Width (ms)

The PPS Pulse width (set in milliseconds) may be changed if required and is configurable within a range of 1 to 500 milliseconds.


### 3.3.2.3 Corrections (LD8)



*Receiver Management – Corrections (LD8 example)*

#### RTK > Source


Users can receive RTK corrections in the RTCM v3 format by selecting AUTO for the Source.



*RTK – Source*

#### VERIPOS > Mode


The **Mode** determines which L-band beam management options are available. Setting the Beam Mode to **DISABLED** will simulate the failure of corrections, which is useful in failure mode and effects (FMEA) testing. When using Mode **AUTOMATIC**, the receiver will track and use data from up to three beams simultaneously, with tracking determined based on the receiver location and the highest elevation beams. Using Mode **AUTOMATIC** mitigates against the impact of a single beam loss. Additionally, selecting the most appropriate beam for any given location will not be required whilst transiting across multiple regions in this mode.



*AUTOMATIC beam selection*

#### L-band > Mode > MANUAL

When tuning to **MANUAL**, users can choose an available beam or add a USER-defined beam. Do not switch the **Beam** option to **USER** unless instructed to by Veripos support.



*MANUAL beam selection*

### NTRIP > Mode

This option allows the user to toggle between having NTRIP **DISABLED** or **ENABLED**.


If enabled, the LD8 can receive Veripos RTCM corrections via NTRIP. An NTRIP service activation from Veripos Support is necessary for use, and the LD8 must also be connected directly to a network with external access to obtain Veripos NTRIP caster data.



#### CAUTION

NTRIP should only be enabled if included in the Veripos SAL. Please contact Veripos support to confirm if you are unsure.

To configure the LD8 to receive VERIPOS corrections via NTRIP, firstly use an internet-connected laptop on the same network as the LD8 and browse to the Veripos NTRIP caster <http://sid-output.com:2101> to verify that connections via port 2101 are available. The browser should reply with four lines of structured binary data. No reply may suggest that port 2101 is blocked, which can be resolved by contacting local IT support. Upon establishing a successful connection NTRIP may be **ENABLED**.



*NTRIP Mode*

### SBAS > SBAS Control

This option allows the user to switch **SBAS** correction fallback to **DISABLED** or **AUTOMATIC**.

When the option AUTOMATIC is selected, fallback will be available in case of a Veripos solutions failure. When DISABLED, the solution will revert to uncorrected in case of a Veripos solutions failure. Use of the SBAS solution will only occur should Veripos solutions be unavailable.




*SBAS – SBAS Control*



#### NOTE

SBAS corrections are not available in all regions, additionally the SBAS service is not under the control of Veripos.


### 3.3.2.4 Corrections (LD900)



*Receiver Management – Corrections (LD900)*

#### RTK > Source


The LD900 is capable of receiving RTK corrections. Enable RTK by selecting AUTO for the Source.



*RTK – Source*


#### VERIPOS > LBAND / GNSS1 Antenna

Upon clicking the LBAND or GNSS1 Antenna settings cog, users can configure inputs for either Mode. Setting the Mode to **DISABLED** will simulate the failure of corrections, which is useful in failure mode and effects (FMEA) testing. When using the default of Mode **AUTOMATIC**, the receiver will track and use data from up to three beams simultaneously, with tracking determined based on the receiver location and the highest elevation beams. Using Mode **AUTOMATIC** can mitigate against the impact of a single beam failure or masking. Selection of the most appropriate beam for any given location will not be required whilst transiting across multiple regions in this mode.



*LD900 LBAND Antenna Mode settings*

Selecting **MANUAL** will provide additional LBAND beam management options. An available **Beam** can be selected, or a **USER**-defined beam added.



The interface shows two rows of radio buttons. The first row is labeled 'Mode' and contains three options: 'DISABLED', 'AUTOMATIC', and 'MANUAL'. The 'MANUAL' option is selected. The second row is labeled 'Beam' and contains six options: '98W', 'AORW', '25E', 'IOR', '143.5E', and 'USER'. The '25E' option is selected.

*Manual beam selection*

The user may select pre-configured Veripos beam frequency or switch to **USER**.

Switching the **Beam** option to **USER** will allow for the input of a USER beam. Do not use unless instructed to by Veripos support.



The interface shows a 'Beam' row with radio buttons for '98W', 'AORW', '25E', 'IOR', '143.5E', and 'USER'. The 'USER' option is selected. Below this, there is a 'Frequency(MHz)' input field with a default value of '25E'. Below that is a 'Bit rate' slider with a default value of '1200'.

*User Beam options*

### NTRIP > Mode

This option allows the user to toggle between having NTRIP **DISABLED** or **ENABLED**.


If enabled, the LD900 can receive Veripos RTCM corrections via NTRIP. An NTRIP service activation from Veripos Support is necessary for use, and the LD900 must also be connected directly via LAN1 to a network with external access to obtain Veripos NTRIP caster data.



#### CAUTION

NTRIP should only be enabled if it is included in the Veripos SAL. Please contact Veripos support to confirm if you are unsure.

To configure the LD900 to receive VERIPOS corrections via NTRIP, firstly use an internet-connected laptop on the same network as the LD900 and browse to the Veripos NTRIP caster <http://sid-output.com:2101> to verify that connections via port 2101 are available. The browser should reply with four lines of structured binary data. No reply may suggest that port 2101 is blocked, which can be resolved by contacting local IT support. Upon establishing a connection NTRIP may be **ENABLED**.



The interface shows a section titled 'NTRIP' with a 'Mode' row containing two radio buttons: 'DISABLED' and 'ENABLED'. The 'DISABLED' option is selected. Below the radio buttons, it says 'Default: Disabled'.

*NTRIP Mode*

### MF > Source

The MF Source setting can be toggled between **ENABLED** and **DISABLED**, defaulting to **ENABLED**.




#### NOTE

The MF option will only be available on Quantum if MF is available for the LD900.

### MF > Receiver Mode

**Receiver Mode** can be set to either **AUTOMATIC** or **MANUAL**. **AUTOMATIC** will cause the MF receiver to lock onto the highest quality MF signal detected. **MANUAL** will require an MF station **Frequency(kHz)** to be entered, restricted to the range of 283.5 to 325.0 kHz:



### SBAS > SBAS Control

This option allows the user to switch **SBAS** correction fallback to **DISABLED** or **AUTOMATIC**. When the option **AUTOMATIC** is selected, fallback will be available in case of a Veripos solutions failure. When **DISABLED**, the solution will revert to uncorrected in case of a Veripos solutions failure. Use of the SBAS solution will only occur should Veripos solutions be unavailable.




*SBAS – SBAS Control*



#### NOTE

SBAS corrections are not available in all regions, additionally the SBAS service is not under the control of Veripos.


### 3.3.2.5 Heading (LD8)



*Heading configuration (LD8)*


#### Heading Output (LD8) > Offset

Will appear all times. It can be set to a value between  $-180^{\circ}$  and  $180^{\circ}$ . This option allows for an offset to be applied to the calculation. Any offset value entered in here will be applied to Heading outputs from the GNSS receiver.





### 3.3.2.6 Heading (LD900)




*Heading configuration (LD900)*

If licensed, the LD900 can be used to compute heading. However, if the applied Quantum license does not support heading, then Quantum will not display this item. Quantum can also input Heading from an external source via Serial or TCP/IP.

#### Heading Output (LD900)

This option toggles whether a heading output is available.




#### Heading Output (LD900) > Offset

Will appear when Heading Output is ENABLED. It can be set to a value between -180° and 180°. This option allows for an offset to be applied to the calculation. Any offset value entered in here will be applied to Heading outputs from the GNSS receiver.



### 3.3.2.7 INS (LD900)



INS configuration (LD900)

Where licensed, LD900 and LD900M model receivers interfaced to an appropriate IMU will be capable of INS.

#### Enabling INS

Toggling INS to **ENABLED** will allow for configuration of INS options. Use **Apply** to save any changes made.

#### IMU > Type

The two INS IMUs supported for use within Quantum are the **ISA-100C** and the **μIMU-IC**.

#### IMU > Port

The LD900 COM port which the IMU is being interfaced on (**COM1**, **COM2** or **COM3**) can be selected here.

#### IMU > IMU Installation > Rotational Offset

This field allows the user to enter Rotational Offset X, Y and Z values within a -180.00° to +180.00° range.

#### IMU > IMU Installation > IMU to Antenna Offset

This field allows the user to enter Primary (GNSS1) Antenna Translational Offset X, Y and Z values.

**IMU > IMU Installation > IMU to User Reference Point**

The User Reference Point represents a user-defined point or location, set separately from the INS and Antenna Reference Points. This reference point is not inherently part of the system's internal calculations but is rather a user-defined offset or adjustment applied to the INS-derived position or to align with specific user requirements.

By specifying X, Y, and Z value adjustments to shift the calculated position users may align the User Reference Point with external references.


**IMU > IMU Installation > Heave Filter Period**

The Heave addresses heave motion (vertical movement of vessel in response to waves or other disturbances) and represents the duration of time which the filter analyses and adjusts for vertical displacement variations of the vessel. A shorter filter period might provide more frequent updates but may be susceptible to noise, while a longer filter period may smooth out the data but could introduce a delay in responding to changes in heave motion.

The time entered in seconds will determine how quickly the INS can adapt to changes in the vertical motion of the platform while maintaining accuracy and stability.

With an understanding of the trade-offs between responsiveness and noise filtering Users may adjust the Heave Filter period based on operational scenario requirements.

### 3.3.2.8 I/O Serial



*I/O Serial configuration (LD900 example)*

Serial ports can output active calculation data or input correction data from an external source.

#### COM#

Select the COM port that requires setting up. Both the LD8 and LD900 COMs 1-3 support baud between 1200 and 460800, set to a default baud of 9600.



#### CAUTION

While official NMEA 0183 Standard specifies 4800 as the default baud for most communication, it is recommended to use 9600 bits per second and above. Lower baud, such as 2400, should generally be avoided, as the reduced data transmission speed may result in delayed or missed updates, particularly in systems requiring frequent position or heading data.

The LD900 additionally includes the following:

#### Without the use of a 3-port Aux cable on DB15HD connector on COM4 Aux Port:


- COM4, supporting 9600 to 460800 baud.

#### With the use of the 3-port Aux cable on DB15HD connector:

- COM4, supporting 9600 to 460800 baud.
- COM5, supporting 9600 to 460800 baud for the output of secondary positioning.
- COM6, supporting a fixed baud of 38400 for correctional inputs (RTK, IOLAN, UHF).

#### COM# > Type

The COM communication type options are NONE, OUTPUT, or INPUT. When selecting **NONE**, all inputs and outputs for that port will cease. When selecting either **OUTPUT** or **INPUT** further configuration options will appear.




### COM# > Type > Output

Selecting **OUTPUT** will allow for selection of **NMEA** (**GGA**, **GSA**, **GSV**, **GST**, **VTG**, **RMC**, **GLL**, **GRS**, **ZDA**, **HDT**\*, **INHDT**\*\*, and **PASHR**\*\*), **UKOOA**, **TRINAV** (V3 or V4 as configured in [Position](#)), **VERIPOS** (Veripos corrections), **INS**\*\* (**TSS1**, **HEAVE**, **INSPVA**, **INSSTDEV**, **SYNCHEAVE** and **DELAYEDHEAVE**) and **OTHERS** (**BESTPOS**, **BESTGPSPOS**) message data outputs.

\*Requires heading to be enabled and licensed.

\*\*Requires INS to be licensed and enabled



**COM1**

Type: ☐ NONE ☒ **OUTPUT** ☐ INPUT

Output: ☒ **NMEA** ☐ UKOOA ☐ TRINAV ☐ VERIPOS ☐ INS ☐ OTHERS

Baud Rate: 9600 Protocol: ☒ RS232 ☐ RS422

Stop Bits: ☒ 1 ☐ 2 Data Bits: ☐ 7 ☒ 8

Parity Bits: ☒ NONE ☐ ODD ☐ EVEN

NMEA Output Rate: 1


Messages:

<input type="radio"/> On <input checked="" type="radio"/> Off GGA	<input type="radio"/> On <input checked="" type="radio"/> Off RMC
<input type="radio"/> On <input checked="" type="radio"/> Off GSA	<input type="radio"/> On <input checked="" type="radio"/> Off GLL
<input type="radio"/> On <input checked="" type="radio"/> Off GSV	<input type="radio"/> On <input checked="" type="radio"/> Off GRS
<input type="radio"/> On <input checked="" type="radio"/> Off GST	<input type="radio"/> On <input checked="" type="radio"/> Off ZDA
<input type="radio"/> On <input checked="" type="radio"/> Off VTG	<input type="radio"/> On <input checked="" type="radio"/> Off INHDT
<input type="radio"/> On <input checked="" type="radio"/> Off PASHR	

Type - Output

### COM# > Type > Input

Selecting **INPUT** will allow for the input of external **VERIPOS** corrections, **RTCMV2** (3rd party DGNSS RTCM v2 corrections), **RTCMV3** (3rd party RTK or DGNSS RTCM v3 corrections), **CMR** (RTK correction data), **IOLAN** (NTRIP serial connections) or **NOVATELX** (NovAtel format corrections).



**COM1**

Type: ☐ NONE ☐ OUTPUT ☒ **INPUT**

Default: None

Input: ☒ **VERIPOS** ☐ RTCMV2 ☐ RTCMV3 ☐ CMR ☐ IOLAN ☐ NOVATELX

Default: Veripos

Baud Rate: 9600 Protocol: ☒ RS232 ☐ RS422

Default: 9600

Stop Bits: ☒ 1 ☐ 2 Data Bits: ☐ 7 ☒ 8

Default: 1

Parity Bits: ☒ NONE ☐ ODD ☐ EVEN

Default: None

Type – Input (Veripos example)

### Baud Rate


Baud **1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400** and **460800** is available.



#### CAUTION

While official NMEA 0183 Standard specifies 4800 as the default baud for most communication, it is recommended to use 9600 bits per second and above. Lower baud, such 2400, should generally be avoided, as the reduced data transmission speed may result in delayed or missed updates, particularly in systems requiring frequent position or heading data.

Select an appropriate baud for the required bandwidth of message type output:



### Protocol

Users may set Protocol to RS232 or RS422. Options differ between the LD8 and LD900, use the below table as a reference:

	COM1 & COM2	COM3	COM4	COM5	COM6
LD8	RS232 / RS422	RS232	--	--	--
LD900	RS232 / RS422	RS232 / RS422	RS232* / RS422*	RS232* / RS422*	RS232** / RS422**

\*Output only    \*\*Input only

### Stop Bits

Users may set Stop Bits to 1 or 2.

### Data Bits

Users may set Data Bits to 7 or 8.


### Parity Bits

Users may set Parity Bits to NONE, ODD or EVEN.

### NMEA Output Rate

Except for LD900 COM4 and COM5, which are restricted to 1Hz, when selecting NMEA data outputs (the number of NMEA outputs within 1 second), rates of 1, 2, 5, 10 and 20 Hz are available. If selecting INS data outputs on LD900 units, rates of 1, 2, 5, 10, 20, 50, 100 and 200 Hz are available.

### 3.3.2.9 I/O Network



*Receiver Management – I/O Network (LD900)*

For the LD8, five TCP/IP ports are available, **ICOM1** (3001), **ICOM2** (3002), **ICOM3** (3003), **ICOM4** (3004) and **ICOM5** (3005).

For the LD900, either seven TCP/IP ports will be available, **ICOM1** (3001), **ICOM2** (3002), **ICOM3** (3003), **ICOM4** (3004), **ICOM5** (3005), **ICOM6** (3006) & **ICOM7** (3007), or a **MOXA** tab will appear (see next section).

Each port can be configured to output active calculation data.

#### **ICOM# > Type**


The I/O Network port options are **NONE**, **OUTPUT**, or **INPUT**. When selecting **NONE**, all inputs and outputs for that port will cease. When selecting either **OUTPUT** or **INPUT** further configuration options will appear.

## ICOM# > Type > Output

Selecting **OUTPUT** will allow for selection of **NMEA** (**GGA**, **GSA**, **GSV**, **GST**, **VTG**, **RMC**, **GLL**, **GRS**, **ZDA**, **HDT\***, **INHDT\*\***, and **PASHR\*\***), **UKOOA**, **TRINAV** (V3 or V4 as configured in [Position](#)), **VERIPOS** (Veripos corrections) and **INS\*\*** (**TSS1**, **HEAVE**, **INSPVA**, **INSSTDEV**, **SYNCHEAVE** and **DELAYEDHEAVE**), **DATA LOGGER** and **OTHERS** (**BESTPOS**, **BESTGPSPOS**) message data outputs.

\*Requires heading to be enabled and licensed.

\*\*Requires INS to be licensed and enabled



Type - Output

## ICOM# > Type > Input

Selecting **INPUT** will allow for the input of external **VERIPOS** corrections, **RTCMV2** (3rd party DGNSS RTCM v2 corrections), **RTCMV3** (3rd party RTK or DGNSS RTCM v3 corrections), **CMR** (RTK correction data), **IOLAN** (NTRIP serial connections) or **NOVATELX** (NovAtel format corrections).

### Protocol

The LD900 can output and input TCP and UDP protocol on all I/O Network ports.

### End Point Address

Selecting TCP will allow for the entry of an end-point address between 0.0.0.0 and 255.255.255.255.

### Port

When using either TCP or UDP protocol the port number can be set within a range of 1 – 65535.


### NMEA Output Rate

When selecting NMEA data outputs (number of NMEA outputs within 1 second) rates of 1, 2, 5, 10 and 20 Hz are available. If selecting INS data outputs on LD900 units, rates of 1, 2, 5, 10, 20, 50, 100 and 200 Hz are available.



### 3.3.2.10 MOXA (LD900)

Where required an optional Moxa serial port expansion unit can be used to convert ICOM to serial. If this has been interfaced, then a MOXA tab will be available within the Receiver Management page.



Select **P1**, **P2**, **P3**, **P4**, **P5**, **P6** or **P7**, depending on which port requires setting up.



#### NOTE

The settings of P7 will be duplicated to P8.

#### P# > Type

The intended COM communication type will be either **NONE**, **OUTPUT** or **INPUT**. When selecting **NONE** all input and outputs for that port will cease. When selecting either **OUTPUT** or **INPUT** further configuration options will appear.

#### P# > Type > Output

Selecting **OUTPUT** will allow for selection of **NMEA** (**GGA**, **GSA**, **GSV**, **GST**, **VTG**, **RMC**, **GLL**, **GRS**, **ZDA**, **HDT\*** and **PASHR\*\***), **UKOOA**, **TRINAV** (V3 or V4 as configured in [Position](#)), **VERIPOS** (Veripos corrections) and **INS\*\*** (**TSS1**, **HEAVE**, **INSPVA**, **INSSTDEV**, **SYNCHEAVE** and **DELAYEDHEAVE**) message data outputs.


\*Requires heading to be enabled and licensed.

\*\*Requires INS to be licensed and enabled



## P# > Type > Input

Selecting **INPUT** will allow for the input of **VERIPOS** corrections, **RTCMV2** (3rd party DGNSS RTCM v2 corrections), **RTCMV3** (3rd party RTK or DGNSS RTCM v3 corrections) or **CMR**.



## Baud Rate


Baud **1200**, **2400**, **4800**, **9600**, **19200**, **38400**, **57600**, **115200**, **230400** and **460800** is available.



### CAUTION

While official NMEA 0183 Standard specifies 4800 as the default baud for most communication, it is recommended to use 9600 bits per second and above. Lower baud, such as 2400, should generally be avoided, as the reduced data transmission speed may result in delayed or missed updates, particularly in systems requiring frequent position or heading data.

Select an appropriate baud for the required bandwidth of message type output:



## Protocol

The LD900 can input and output **RS422** and **RS232** protocol on P1-P7.

## Stop Bits

Stop Bits can be set to **1** or **2**.

## Data Bits

Data Bits can be set to **7** or **8**.

## Parity Bits


Parity Bits can be set to **NONE**, **ODD** or **EVEN**.

## NMEA Output Rate

When selecting NMEA data outputs (number of NMEA outputs within 1 second) rates of 1, 2, 5, 10 and 20 Hz are available. If selecting INS data outputs on LD900 units, rates of 1, 2, 5, 10, 20, 50, 100 and 200 Hz are available.

### 3.3.2.11 GRIT

The GRIT tab allows for the enabling of **Spoofing Detection** and **Interference Detection**.



#### NOTE


When **licensed** for Interference Mitigation the option to configure filters will become available via the [Spectrum view](#).

### Spoofing

Upon first access, Spoofing will be DISABLED. Toggling DISABLED to **ENABLED** will display Spoofing Detection on the Quantum screen.


### Calibration Status

This non-configurable field will appear when Spoofing is **ENABLED**, highlighting the Spoofing Calibration Status.



### Start Calibration / Restart Calibration

If the Calibration Status is not PASSED, an option to Restart Calibration is available. Clicking this option will result in the display of the below dialog:



Upon clicking **OK**, calibration of Spoofing Detection will commence. This process will take a few minutes, **do not power off the receiver until the process is complete. Once complete, the GNSS card will reboot.**




#### CAUTION

The calibration of spoofing detection will restart the PPP calculation. PPP convergence will require time; during this time, a Standard/Standard2 solution will be output from the receiver until the PPP solution becomes available.

### Interference


Upon first access, Interference will be DISABLED. Toggling DISABLED to **ENABLED** will display Interference Detection on the Quantum screen.



Use **Apply** to save any changes made.

### 3.3.2.12 Antenna Voltage (LD8)

The Antenna Voltage tab allows for toggling of antenna voltages between **On** or **Off**:



*Receiver Management - Antenna Voltage (LD8)*




#### CAUTION

Turning off the voltage may stop the antenna receiving power and result in a loss of signal reception. The voltage should only be turned off when signals are received through a RF splitter with another power source.

### 3.3.2.13 Antenna Voltage (LD900)

The Antenna Voltage tab allows for toggling of antenna voltages between **On** or **Off**:



*Receiver Management - Antenna Voltage (LD900)*




#### CAUTION

Turning off the voltage may stop the antenna receiving power and result in a loss of signal reception. The voltage should only be turned off when signals are received through a RF splitter with another power source.

## 3.4 System Status

The **System Status** menu displays information relating to the Quantum configuration, such as details of the connected Veripos receiver and the Quantum software version.



### General

Displays the name of the active Quantum Configuration:



*System Status - Active Configuration name*

## Receiver

<b>IP</b>	Shows IP address of the connected Veripos receiver.
<b>Serial Number</b>	Displays unit ID of the connected Veripos receiver.
<b>System Version</b>	Displays System Version of the connected Veripos receiver.
<b>GNSS Card Details</b>	Displays GNSS card model information (not applicable for LD900)

Receiver	
IP	192.168.2.8
Serial Number	841296
GNSS Card Details	NovAtel OEM7720-1.00

*System Status – Receiver*

## Software

Displays Quantum software version numbers (your version may differ):

Software	
Quantum Version	7.0.0

*System Status – Software*

## Performance


Displays system resource information. The scroll down arrow can be used to slide the bar to view the performance menu:

CPU	8%
Memory Free	2.22/7.88GB
Disk Free (C:)	90.42/237.54GB

*Performance information*

## Launch Engineering View


This option provides advanced information on L-band and GNSS signal tracking. Veripos may request information from the Engineering view during support cases. It is recommended to only use this view when under instruction from Veripos:



*Engineering View*

## 3.5 Authorisations

The Authorisations menu displays information relating to system licencing.



*Authorisations (LD900 example)*

### 3.5.1 Receiver

#### Signal licenses

Quantum displays signal licence information relating to the type of correction service that is enabled on the interfaced Veripos IMU. This license information is **not** the Quantum software license.

Information on the three type of available Veripos solution (Apex, Ultra and Standard) is displayed. Each solution indicates which GNSS constellation is subscribed.

In the example below, the Veripos receiver has been enabled for the Apex5 service, which uses four GNSS constellations. GPS and GLONASS appearing next to Ultra and Standard indicates that the receiver has the backup services of Ultra<sup>2</sup> and Standard<sup>2</sup>.

Signal Licenses	
Apex PRO	GPS GLONASS Beidou Galileo
Ultra	GPS GLONASS
Standard	GPS GLONASS

*Signal Licences information*



## GNSS Receiver licenses

This section displays which GNSS constellations and frequencies the GNSS receiver has the capability to track.

GNSS Receiver Licenses	
GPS	L1 L2 L5
GLONASS	L1 L2 L3
Beidou	B1 B2A B2B B3
Galileo	E1 E5A E5B E6




GNSS Receiver Licences information

### 3.5.1.1 GNSS1 / GNSS2 / L-band (LD900)

This section displays the PSN and Model of the GNSS 1, GNSS 2 and L-band receivers.

To purchase additional receiver functionality, e-mail the serial number of the LD900 system to your Veripos account manager. When requesting GNSS 2 secondary positioning, include the GNSS 2 PSN serial. Upon receipt of an authorisation code, apply this to the correct receiver by clicking the corresponding **Apply New Authcode** button:

- Apply Heading upgrades within the GNSS 1 section.
- Apply INS upgrades within the GNSS 1 section.
- Apply Secondary Positioning upgrades within the GNSS 2 section.

GNSS 1	
PSN	BMHR19210388K
Model	FFNRYNTVEP4A
	 Apply New Authcode
GNSS 2	
PSN	BMRU18500217S
Model	DDNNZNNNEA
	 Apply New Authcode
L-band	
PSN	BMRU18500225B
Model	DSNNNTVEA
	 Apply New Authcode

GNSS Receiver Licences information



#### NOTE

Authcodes may take up to ten minutes to apply and require a receiver reboot.

### 3.5.2 Quantum

#### Software licenses

A Quantum software license is required. This is normally entered during the initial configuration process. The Software Licenses section displays the active Quantum license code and the enabled features of the license. Licenses can either be purchased (no expiry) or rented. Rented licenses have an expiry date and will need to be renewed.

The following modes are currently available:


- **DP** Enables Quantum optimised for DP operations
- **Survey** Enables Quantum optimised for Survey operations

The following features are currently available:


- **Heading** Enables the use of heading functionality
- **Tides** Enables the use of Tides functionality
- **INS** Enables the use of INS functionality
- **Interference Mitigation** Enables interference mitigation technology functionality

When requesting a new or revised software license, it is important to ensure that the appropriate features are requested.

A new Software licence code can be applied by clicking **Apply New License**, then entering the supplied license code and finally clicking **Apply**:



*Software licence details – Purchased license*



*Apply New Licence*

If a license is rented, the rental expiry date of the Quantum software license will be shown below the list of enabled features:

Quantum	2WR2-EQQV-UPN2-HSC5	
Enabled Features	Purchased	Rented
		no
		Expires 28/11/2016

*Software licence details – Rented license*


It is possible to have a combination of purchased and rented licenses. For example, the main Quantum license (DP or Survey) is purchased and an additional feature such as Heading could be rented. In this scenario, a license expired notification will appear periodically. If the expired feature is required a new license can be obtained by contacting Veripos Support. If a feature is no longer required, the expired feature can be cleared by clicking Acknowledge. This will prevent the notification from appearing and it will remove the expired feature from the Software Licenses section.

Quantum	J6R2-GQYV-UNJ6-HSDT	
Enabled Features	Purchased	Rented
	DP	Heading
		Expires 15/07/2016
		Acknowledge

*Software licence details – Rental Acknowledge*

### 3.5.2.1 Expired Licenses


If a rental license has expired, the notification message shown below will be displayed at regular intervals. Contact Veripos Support to obtain a new license:



*License Expired notification*

## 3.6 Display

The **Display** settings page allows display setting changes.



### 3.6.1 General


#### 3.6.1.1 Latency Indicator Direction

The **Latency Indicator Direction** setting controls the timeout graphic used to display corrections Latency:




*Latency Indicator Direction setting*

By default, this is set to **Down**. When set to Down, the correction latency bars will count down from the maximum correction age (360 seconds for PPP, 120 seconds for DGNSS solutions):



*PPP Correction Latency – Counting down*




*DGNSS Correction Latency – Counting down*


To change the **Latency Indicator Direction**, click **UP** followed by **Apply**.

Once **Apply** is selected a momentary message: **Changes Successfully Applied** will appear.

When set as **UP** the correction latency bars will count up from zero:



*PPP Correction Latency – Counting up*



*DGNSS Correction Latency – Counting up*

For further details regarding the Correction Latency view, refer to section **Correction Link Satellites**.

### 3.6.1.2 Latency Pulse Speed

The **Latency Pulse Speed** setting defines how fast or slow the **Correction Age** and **Solution Status** icons will pulse, ranging from 0 and 1 seconds (0.2 increments). A setting of 0 will disable the pulsing. It is recommended to leave the icons pulsating as this will show that the Quantum system is active:



*Latency Pulse Speed setting*

### 3.6.1.3 Full Screen

Quantum does not launch in full screen by default; however a full screen view can be enabled:




*Latency Pulse Speed setting*

### 3.6.2 Heading Display

Heading display settings are only visible when the system is licensed and configured for Heading.

#### DP/Survey:

The Heading display page allows users to change Track Plot, SOG, COG and Tracking display settings:



*Heading Tiles configuration*

#### 3.6.2.1 CoG and Tracking Display

Defines the minimum vessel velocity at which the CoG marker and track plot will update. This threshold velocity should be defined to suit the vessel dynamics.



*CoG and Tracking Display setting*

#### 3.6.2.2 Speed Over Ground Units

Choose the units which vessel speed is displayed in. Choose between KNOTS, M/S or KM/H.




*Speed Over Ground Units setting*



### 3.6.2.3 Tracking

Tracking settings are used to change the style of the vessel track plot within the Heading view.



*Heading view with track plot displayed*

### 3.6.2.4 Track Plot

Choose if a track plot is to be **DISABLED** or **ENABLED**. Fields relevant to track plot will be shown once track plot is enabled.



*Track Plot setting*

### 3.6.2.5 Track Plot Point Type

Choose the type of track plot point symbol to be displayed (either an Arrow or Circle).



*Track Plot Point Type setting*

### 3.6.2.6 Track Plot Line

The vessel track plot can be configured as isolated points or interconnected with lines.



*Track Plot Line Type setting*

### 3.6.2.7 Number of track points to display

Defines the number of historical track points to be displayed.



*Number of track points to display setting*

### 3.6.2.8 Track Plot Frequency

Defines the interval (and therefore frequency) at which points will be plotted. A high track plot frequency value may result in the display becoming cluttered. Clutter can be reduced by decreasing the track plot frequency (increasing the interval).



*Track plot frequency setting*

### 3.6.2.9 Track Plot Transparency

Defines the transparency of vessel track plots. The maximum transparency value is 80%.



*Track plot transparency setting*

## 3.6.3 Vessel Display

### DP/Survey:


The Vessel Display page allows users to change colour and type of vessel.



*Vessel Display settings for DP/Survey*

### 3.6.3.1 Colour

This option allows users to select colour of vessel graphic to be displayed on the Heading and navigation plot tiles. The default colour of the vessel graphic is grey.



*Vessel colour*

### 3.6.3.2 Type


Type allows Survey users to select the vessel type, Ship or Rig:



*Vessel Type for Survey/DP*

### 3.7 Notifications


Quantum can log significant events as notifications, these logs can be **DISABLED** or **ENABLED** (recommended).



For more detailed information on Quantum notifications, please refer to section **Display Tabs**.


## 3.8 Screensaver

Quantum has a screensaver feature (enabled by default) which is displayed after a defined period of user inactivity. The settings detailed below alter the screensaver behaviour.



### 3.8.1 Screensaver

Configures the screensaver feature to be **DISABLED** or **ENABLED**:



*Screensaver setting*


### 3.8.2 Screensaver Transparent

By default, when the screensaver is ENABLED, the main display is not visible because the screensaver is not transparent:



*Screensaver Transparent setting*

It is possible to make the screensaver transparent so that the main Quantum screen is visible behind the screensaver:



*Screensaver - Transparent disabled    Screensaver - Transparent enabled*

### 3.8.3 Screensaver Wait Time

Used to define when the screensaver will be launched after a period of no user interaction or system events. The default is 30 seconds:



*Screensaver Wait Time setting*

### 3.8.4 Screensaver Logo


Choose if the Veripos target logo is to be included on the screensaver. The default setting is DISABLED.



*Screensaver Logo setting*




*Screensaver Logo Enabled*



*Screensaver Logo Disabled*

### 3.8.5 Screensaver Animation


Defines if animation is used when the screensaver appears or clears. Choose between **DISABLED** and **FADE**. The default setting is **DISABLED**:



*Screensaver Animation setting*

### 3.8.6 Preview Screensaver


Click Preview Screensaver to immediately display the screensaver. This is useful for checking the screensaver appearance following setting changes:



*Preview Screensaver option*


### 3.9 Close Quantum

To close the Quantum software, click **Close Quantum** on the **Settings** page, as highlighted in blue below. Users **should avoid** clicking the 'X' in the Windows top panel, as highlighted in orange:



*Close Quantum*

After clicking **Close Quantum**, a confirmation message will appear, Click **Yes** to close **Quantum**:



*Close Quantum confirmation*




#### NOTE

Closing Quantum will not stop the NMEA or UKOOA position outputs that originate from the Veripos receiver.



## 4 Screen overview

When Quantum has been launched and **System Configuration** has been completed (as detailed in section **System Configuration**), the Quantum screen should appear as below:



Quantum screen layout

The main elements of the Quantum screen are:

- Sidebar
- Menu icon
- Display tabs
- Notifications tab
- Main display screen

### 4.1 Sidebar

The Quantum Sidebar, as seen on the left of the above Quantum screen layout image, displays overall status information for the active solution. The general health of the backup solution is also indicated by the colour and 'pulse' of the circular icon.



#### NOTE

The data displayed within the sidebar is not configurable.

#### 4.1.1 Version number

Just above the Sidebar, the present version of Quantum in use can be found:



### 4.1.2 Solution status

The name of the solution currently in use (active solution) will be displayed e.g. **APEX**. A pulsing circular icon is also displayed which is used to show general solution health.

A green pulsing circle indicates that the active solution is working within expected parameters with no issues. If there are any issues with the active solution, the colour of the solution status symbol will change.

An amber symbol indicates that the active solution is still working, but with some issues e.g. the correction age may be higher than expected.

A red symbol indicates that there is a critical problem with the active solution and positioning e.g. Loss of GNSS or the correction age has exceeded the allowable limit.


A turning blue circular (partial) trail indicates that a solution is converging (and therefore not available):



*Solution Status – Healthy*



*Solution Status – Warning*




*Solution Status – Failed*



*Solution Status – Converging*



*Solution Status – PPP Converged & INS Aligning*



*Solution Status – Blended GNSS / INS*



*Solution Status - GNSS Lost & Dead Reckoning*

### 4.1.3 Satellite constellation

The **Sidebar** shows how many satellites from each relevant constellation are being tracked and how many are being used.

It is normal to see less satellites being used compared to the amount tracked. This is normal because some satellites are:

- Below the defined solution elevation mask
- Below the acceptable signal level mask.
- Not corrected.

Only GNSS constellations and satellites displayed in green are in-use by the active solution:

	In Use	Tracked
GPS	8	8
GLONASS	8	8
BeiDou	5	5
Galileo	7	7

*Sidebar – Satellite Constellation Status*

### 4.1.4 Solution position and height

The Sidebar displays the WGS84 Latitude, Longitude and ellipsoidal height of the active solution which is being provided by the Veripos receiver.

Latitude and Longitude are displayed in DD:MM:SS.SSS format. Height is displayed in metres to 2 decimal places:

```
57° 12' 04.921" N
002° 11' 32.270" W
114.40m
```

*Sidebar – Position & Heading*


### 4.1.5 HDOP, 2d-SD and V-SD

The **Horizontal Dilution of Precision (HDOP)** value is a measure of the quality of satellite horizontal geometry. A low satellite count typically leads to high HDOP values. Persistently high HDOP values may indicate issues with antenna obstructions or interference. The HDOP value is color-coded as follows:

- Green: Healthy HDOP (< 2.0)
- Amber: Moderate HDOP (2.0 to 4.0)
- Red: Poor HDOP (> 4.0)

The **Standard Deviation (2d-SD)** value, expressed at a 95% confidence level, indicates the 2D accuracy of the active solution in meters. A smaller 2d-SD value corresponds to better solution accuracy.


The **Vertical Standard Deviation (V-SD)**, similar to 2d-SD, is expressed at a 95% confidence level and indicates the vertical accuracy of the active solution in meters. A smaller V-SD value corresponds to better vertical solution accuracy.



Sidebar – HDOP, 2d-SD and V-SD

### 4.1.6 Interference

Upon enabling [Interference Detection](#), an Interference indicator will appear, which will illuminate amber upon detection of interference within the L1, L2 or L5 signal bands. If Quantum detects targeted jamming, this will change to a red-illuminated Jamming indicator:



Sidebar - Interference detected



Sidebar - Jamming detected

See the [Interference Status](#) tile for frequency information or the [RF Spectrum](#) tile to help determine where the inference centre frequency lies in MHz.

### 4.1.7 Spoofing

Upon enabling [Spoofing Detection](#), a Spoofing indicator will appear. The possible Spoofing indicator states are:

- Grey - Disabled
- Amber - Enabled but not calibrated
- Green - No spoofing detected.
- Red - Spoofing detected.

### 4.1.8 Backup solution

In most circumstances, there will be a **backup** solution in addition to the active solution. The Quantum sidebar displays the name and status of the backup solution.

Backup solutions are typically secondary PPP solutions or a Standard solution. However, if no other backup solutions are available a backup solution may be an uncorrected position. In the event that only an uncorrected position (stand-alone position) is the backup, the sidebar will display an amber border.

### 4.1.9 Tides solution

The Tides Solution panel is displayed below the sidebar and indicates the Tides status. This solution panel is not displayed unless the Quantum Tides feature is activated. See [Software licenses](#) for details.



*Sidebar – Tides status*

## 4.2 Main Display Screen

The “Main Display Screen” consists of configurable view tiles. Full details options see section Display configuration.

### 4.3 Date and time

The date and time displayed below the Veripos Logo is received from the connected Veripos receiver. Time is displayed in UTC:



*Veripos logo, date and time*

### 4.4 Menu icon

The Menu icon is used to access all Quantum configurations, ranging from initial setup to view configuration.

### 4.5 Display Tabs

**Display Tabs** allow users to setup configurable views. Multiple display tabs can be configured (maximum of 4). For further details please refer to section Display configuration.

### 4.6 Notification Tab


The Notifications Tab is used to notify users of any significant systems events. The tab will show a icon with the number of current system notifications:



*Notification count*


### 4.6.1 Viewing notifications

Click the Notification tab to display the list of system notifications. Notifications are split into two categories – **Status** and **Status History**:




*Current and Historical Status list*

Events, such as system error states which are currently active, will be displayed in the Status section. These could relate to loss of GNSS, loss of corrections data or poor GNSS quality which all would impact system performance:




*Example of a current event notification*

Historical Status notifications generally require no user intervention. These are usually events such as L-band beam changes. Notifications raised in the Status section will move to the Historical Status section once the event is resolved (e.g. system error):



*Example of Historical Status notification*

To view full details of a notification, click on the desired notification. If there is an issue with the system, the event description often contains useful troubleshooting guidance:

 263

**GNSS - GLONASS Lost**, occurred at 09:22:33 on thu 18 apr

---

**Description**


GNSS data is not being received from the GLONASS constellation. If the problem persists check: settings and connections, interference sources, contact the Veripos Helpdesk.

*Full notification summary*

## 4.7 Screensaver


Quantum has an optional screensaver which provides an overall system status and displays a system label. This is defined on the top of the Quantum screen and is useful for monitoring the status of the software at a distance from the monitor. If critical issues arise the screensaver will cease.

Refer to section **Screensaver** for more information on screensaver configuration:




*Screensaver clears when critical alarm present*

Green pulsing circles on the screensaver are used to indicate that the active solution and backup solution are healthy:



*Screensaver solution status indicator – Healthy*

The screensaver will remain active during amber events, such as high correction age. During such Amber events the relevant solution will be displayed in amber. An example is shown below:




*Screensaver solution status indicator – Amber*



## 5 Display configuration

### 5.1 Tab configuration

Quantum allows a maximum of four view tabs:



View tabs can consist of either preset tile layouts or tile layouts containing manually selected views.

#### 5.1.1 Preset tile layouts


There are three predefined layouts:

- Default
- Heading (only present when authorised for Heading)
- GRIT

To select a preset tile layout, click the Menu icon (≡) followed by the large '+' icon. Select the page layout icon:




Available preset tile layouts will display:



*Accessing preset layout options*

Click on the desired view. This selected view will now be displayed and the tab for this view will display the preset layout name e.g. **Default**:



*Default tab example*

#### 5.1.1.1 Default tile layout

The **Default** tile layout consists of the following views:

- Satellite Polar Plot
- Solution Difference
- Correction Link Status
- Correction Link Signal Strength
- Correction Age
- Correction Link Signal Strength – Time Series

#### 5.1.1.2 Heading tile layout

The **Heading** tile layout consists of the following views:

- Heading
- Heading Data
- Correction Link Status
- Correction Link Signal Strength
- Correction Age
- Correction Link Signal Strength – Time Series


#### 5.1.1.3 GRIT tile layout

The **GRIT** tile layout consists of the following views:

- Interference Status
- Spoofing Status
- Solution DOP
- Correction Link Signal Strength
- GNSS Signal Level
- 2d-SD – Time Series


## 5.2 User-configurable tile layouts

In addition to preset tile layouts, users can also select specific views to display by clicking on the '+' sign next to the notifications icon:




*Open new tab icon*

The user can choose from one of the four available tile layouts, with arrows providing the ability to scroll through the available tile layouts:



*Select tile layout option*

The available tile layouts are shown below:



*Available tile layouts*

Click on the desired view and the new tab will then appear in Quantum with the chosen tile layout. The tiles will be empty so that the user can manually select which information is displayed within each tile.



### NOTE

The size of the tile dictates which information can be displayed in each. For example, the **2d-SD – Time Series** view can only be displayed within a 2x1 sized tile.

## 5.2.1 Renaming tabs

Any opened display tabs can be renamed. Tiles, which have been manually configured by the user, will be named **New** by default. It is recommended to rename these so that it is easy to identify which views each tab contains. For example, if a tab has views which relate to the L-band correction status the tab could be named '**LBAND**'. Preset tile layout tabs can also be renamed.

To rename a tab, double-click the tab where the current name is displayed, an on-screen keyboard will appear. Type the new name and press **Enter** to confirm:




*On-screen keyboard for renaming tabs*



### NOTE

Tab names are restricted to a maximum of twelve characters and special characters are not permitted.

The new name will now appear within the tab:



*Renamed tab*

## 5.2.2 Deleting tabs

If a tab is no longer required, it is possible to delete it. Simply click on the close icon on the relevant tab:




Delete tab

### 5.2.3 Renaming Quantum screen

In addition to renaming each display tab, it is also possible to rename the title displayed at the top of the Quantum screen. The default name is **System 1**. It is recommended to set a descriptive name such as **DGNSS Port** or **Vessel Secondary**.

To rename the Quantum screen name, double-click the existing name e.g. **System 1**:



Quantum screen name

The new name can be entered using the on-screen keyboard then pressing Enter to confirm:



*New Quantum screen name*



#### NOTE

The name is restricted to 32 characters and no special characters are permitted.


## 6 Views

There are many views available which allow the user to monitor system status. Some of these views relate to the overall solution status and some show more detailed information relating to either GNSS, correction or heading data.

The user can decide which views are most relevant for their requirements and arrange them accordingly.

### 6.1 Selecting views

To manually select views, select the relevant Tab display (either existing or a new tab). Press the Menu icon followed by the '+' symbol then the View icon (highlighted far right below):




*Accessing manual views*

After clicking the **View** icon, the icons below will be displayed:



*View icons*

The available views are split into seven categories, detailed in later sections, these are:





**NOTE**

Heading and Tides tabs are present when Quantum has the feature included within the software license.

Click on the required category to access the available views. Once the required view has been found, press and hold the left mouse cursor and drag to the desired tile.


While dragging the selected view, tiles will be highlighted with a green border or a red border. Green indicates that the view is ok to be placed and red denotes the view is an incompatible shape for this tile.



*Tile placement restrictions*




A selected view must be placed into an appropriate shaped tile dimension:




*View placed in appropriate tile*

### 6.1.1 Different types of tiles available

There are different types of tiles available within views. Namely 1\*1, 2\*1, 2\*2, 3\*3, 4\*4:



*Different types of tiles available (1\*1, 2\*1, 2\*2 & 3\*3)*



*Different types of tiles available (2\*2 & 4\*4)*

### 6.1.2 Deleting view from tiles

If a tile contains information which is no longer required, it is possible to delete the contents of the tile. Simply click on the 'X' icon on the relevant tile:



*Delete tile contents*


### 6.1.3 Replacing existing views

A tile does not need to be empty before a new view can be inserted into a tile. If a tile contains data which is no longer required, a new view can be inserted using the same method as explained in section Selecting views.

## 6.2 Correction View - Descriptions

### 6.2.1 Correction Link Status (LD8)

The **Correction Link Status** view provides high level information regarding various aspects of the L-band corrections in use. Note the information displayed will depend on the size of tile used:




*LD8 Correction Link Status 1x1 view (and) 2x1 view*

Information	Details
L-band satellite in use	Name of the L-band correction satellite in use e.g. AUTO, or 25E
Enabled	Green icon = Enabled Red icon = Disabled
Locked	Green icon = Signal locked Red icon = No signal lock
Sync	Green = Receiving data from L-band satellite Red = Not receiving data from L-band satellite
Signal Strength	Signal strength of the selected L-band satellite. Thresholds: Green: >36.5dB Hz, Amber: Between 32.5 & 36.5dB Hz, Red: <32.5dB Hz
NTRIP	Green icon = NTRIP correction active Grey icon = NTRIP not configured Red icon = NTRIP configured but no corrections received
Azimuth & Elevation	Orientation info' for active L-band correction satellite at present location.

## 6.2.2 Correction Link Status (LD900)

The **Correction Link Status** view provides high level information regarding various aspects of the L-band corrections in use. Note the information displayed will depend on the size of tile used, with toggling between LBAND and GNSS1 available on the 2x1 view, allowing for verification of individual beam states:



LD900 Correction Link Status 1x1 view (and) 2x1 view


Information	Details
LBAND (1x1, 2x1 tiles)	Name of the L-band correction satellite in use e.g. AUTO, or 25E
GNSS1 (1x1 tile)	Name of the L-band correction satellite in use e.g. AUTO, or 25E
Enabled	Green icon = Enabled Red icon = Disabled
Locked	Green icon = Signal locked Red icon = No signal lock
Sync	Green = Receiving data from L-band satellite Red = Not receiving data from L-band satellite

Information	Details
Signal Strength	Signal strength of the selected L-band satellite. Thresholds: Green: >36.5dB Hz, Amber: Between 32.5 & 36.5dB Hz, Red: <32.5dB Hz
NTRIP	Green icon = NTRIP correction active Grey icon = NTRIP not configured Red icon = NTRIP configured but no corrections received

### 6.2.3 Correction Age

The **Correction Age** view shows a breakdown of L-band corrections which the Veripos receiver is enabled for. This view can be used to monitor correction age for all corrections types. The symbols have three colour states based on the current correction age.

Correction types that the Veripos receiver is not enabled for are indicated by a grey icon with a cross. In the example shown below, the system is enabled for Apex Pro, Ultra2 and Standard2:




Correction Age

The table below details the default correction age range which determine the colour of the status icons for each correction service:

Veripos Correction type	Green = time left (seconds)	Amber = time left (seconds)	Red = time left (seconds)
Apex	0 – 179	180 – 359	≥ 360
Ultra	0 – 179	180 – 359	≥ 360
Standard	0 – 79	80 – 119	≥ 120

When displayed in a 1x1 sized tile, the Correction Age view provides high level information of the overall service (no breakdown of each GNSS constellation):




*Correction Age view – 1x1 tile*

## 6.2.4 Correction Link Satellites

The Correction Link Satellites view displays all visible L-band correction satellites (using a satellite symbol) with an elevation of greater than 0° at the user's location.

The polar plot view shows the approximate elevation and azimuth to the correction satellite at the current location. The selected correction satellite will be denoted with the largest satellite symbol:




*Correction Link Satellites view*

## 6.2.5 Correction Latency


Provides a dynamic display of the correction age (latency). The correction latency bars are colour-coded depending on their value.

By default, the latency bars will count down from their maximum allowable latency value. This makes it clear to the user exactly how long they have until that particular solution will timeout (when latency indicator bar reaches zero). A 'Time Left' value is also displayed to confirm how long each solution has until it reaches the maximum allowable correction age:



*Correction Latency – Age counting down*

Veripos Correction type	Green = time left (seconds)	Amber = time left (seconds)	Red = time left (seconds)
Apex	0 – 179	180 – 359	≥ 360
Ultra	0 – 179	180 – 359	≥ 360
Standard	0 – 79	80 – 119	≥ 120



*Correction Latency – Age counting up*


For details on where to set the *Correction* indicator direction refer to section **Latency Indicator Direction**.

The latency bars are colour coded. The tables below show the threshold ranges (count-up and count-down):

Veripos Correction type	Green = time left (seconds)	Amber = time left (seconds)	Red = time left (seconds)
Apex	0 – 179	180 – 359	≥ 360
Ultra	0 – 179	180 – 359	≥ 360
Standard	0 – 79	80 – 119	≥ 120

## 6.2.6 Correction Link Signal Strength


The **Correction Link Signal Strength** view is a fuel gauge-type view which provides real-time LBAND or GNSS1 signal strength indications. The view is colour-coded to give a clear visual indication if the signal strength is acceptable:



*Correction Link Signal Strength view*

## 6.2.7 Correction Link Signal Strength – Time Series

Shows a graphical plot of LBAND or GNSS1 signal strength over the previous 10 minutes:




*Correction Link Signal Strength – Time Series view*

## 6.2.8 Service Correction Availability

Displays information regarding the availability of correction data for each Veripos service.

For Apex and Ultra solutions, the number of GNSS satellites with correction data is displayed in green numbers. GNSS satellites which have no correction data available are displayed in red numbers:



*Service Correction Availability view*




### NOTE

The values in this view are based on all satellites above the horizon (0° elevation). These values may differ from the number of satellites used in a solution which has an elevation mask e.g. 7°.

For Standard solutions the number of Veripos DGNSS reference stations within range of the users' location are shown as the **Total Reference Stations**.

The number of reference stations for which **GPS** and **GLONASS** corrections are currently being received for will be displayed in the GPS and GLONASS bars:




*Service Correction Availability – Standard solution*

Veripos Standard solutions will use a maximum of 6 reference stations even if there are more reference stations within range.



### 6.2.9 SBAS Status

Displays information regarding the availability of SBAS signal status.



*SBAS Status view*


**Signal Strength** is displayed in dBHZ

**PRN** Unique PRN code of satellite in use.

**Status** is shown as a Green, Amber or Red Icon, Green indicates a healthy status, Amber is marginal and Red indicates an unhealthy status.

### 6.2.10 MF Status (LD900 Only)

Displays information regarding the availability of IALA signal status.



*MF Status*


**Signal Strength** is displayed in dBuV

**Station ID** is unique for each IALA reference station, this ID can be used to determine which IALA station is being received. Where no station is available the Station ID will display 1024.

**WER** (Word Error Rate) is ideally 0% which means there are no errors within the decoded data.

A healthy **SNR** (Signal to Noise Ratio) will be indicated with a green indicator, amber indicates a marginal signal and red indicates an unhealthy SNR.

## UHF Status (LD900 Only)



*UHF Status*

**Signal Strength** is displayed in **dBm**

**Frequency** in MHz of the selected UHF channel

**Link Rate** is 4800 BPS.


**Status** is shown as a Green, Amber or Red Icon, Green indicates a healthy status, Amber is marginal and Red indicates an unhealthy status.

## 6.3 GNSS Status View - Descriptions

### 6.3.1 GNSS Availability

Provides information regarding GNSS satellite status:

- **Healthy**            How many useable satellites are tracked
- **Missing**            Number of satellites not tracked
- **Unhealthy**        Number of satellites which are not available for use




*GNSS Availability view*

### 6.3.2 GNSS Missing Satellites

Plots the location of any satellites which should be available at the user's location but are not currently being tracked.


Failure to track available satellites could be due to various reasons, such as masking (blockage) or poor cable or antenna installation. If there are a significant number of missing satellites highlighted in this display, steps should be taken to investigate the cause.



*GNSS Missing Satellites view*


### 6.3.3 GNSS Signal Level

Shows the signal strength, measured in dB Hz for each GNSS satellite in view. There is a toggle switch in the top right of the window, allowing for different signals to be selected. The below example shows GPS satellite signal strengths, with a toggle option to display L1, L2 or L5 signals.



GNSS Signal Levels view on 4X4 tile

The image below shows the GNSS Signal Level 2x1 tile with a toggle switch in the top right of the window, allowing for different signals to be selected.




GNSS Signal Levels on 2x1 tile

GNSS satellites are sorted from left to right by elevation, from lowest to highest.

Veripos solutions have a default GNSS elevation mask of 10°, GNSS satellites that are tracked (but below 10° elevation) will be rejected from the solution. The blue area at the origin of the graph highlights the elevation from 0° to 10°. Satellites within this area will not be used in any solution.

The signal strengths shown are colour-coded to indicate if current signal strengths of tracked satellites are acceptable.


Fluctuations in a satellite signal strength will show as a light blue area at the top of the bar graph plot. Large fluctuations indicate that satellite signal tracking is unstable, which is typical for satellites tracked at low elevations; however, this is also a symptom of multi-path or interference.



The configurable colour-coding thresholds are set to Veripos default values.


### 6.3.4 GNSS Signal Level Alt

Displays the same information as the GNSS Signal Level view but in a different graphical style:




*GNSS Signal Level Alt on 4x4 view*

Recent fluctuation in a satellite signal strength are highlighted by a vertical white line:



*GNSS signal level variation*



GNSS Signal Level Alt view on 2x2 view

### 6.3.5 Satellite Polar Plot


The satellite Polar Plot provides situational awareness, visually representing the orientation of GNSS constellations in relation to the vessel heading. Besides the ability to display heading if available and enabled, the Satellite Polar Plot has the following functions:

Satellite (type)	Description
Tracked satellites	Displays all GNSS satellites currently tracked in green
Tracked satellites (not used)	Displays all GNSS satellites tracked but not used by active solution in grey
Missing satellites	Displays any GNSS satellites not available in red
Correction link satellites	Displays the calculated position of the L Band satellites visible at the vessel's current position



*Satellite Polar Plot view on 4X4 view*

This 4 x 4 view can be configured to show information for specific GNSS Satellite constellations. The 3 x 3 tile polar plot view cannot be customised:




*Satellite Polar Plot view on 3X3 view with no toggles*



### 6.3.6 DOP


Displays the current solution DOP values (HDOP, PDOP and VDOP) of the current solution in green, amber and red when they are in good ( $<2$ ), warning (2 - 4) and bad ( $>4$ ) states.



*DOP view*


### 6.3.7 24 Hour DOP Prediction

Designed to alert the user to periods where the DOP values are predicted to be high. The ability to predict high DOP periods can assist the user to mitigate risks and to maintain additional vigilance. This view can be placed on either a 1x1 or 2x1 tile:



*24 Hour DOP Prediction view*


If no DOP issues are predicted, the main section of the view will be empty and only real-time DOP values (HDOP, PDOP and VDOP) will be displayed:



*24 Hour DOP Prediction view – No events*


### 6.3.8 DOP Status

Displays details of current DOP events. 'DOP events' are periods when DOP values are unusually high, normally because of a low satellite count or poor satellite geometry:



*DOP Status view*

If there are no current DOP events, the main portion of the view will be empty and only real-time DOP values will be displayed. This view can be placed on either 1x1 or 2x1 tile:




*DOP Status view – No events*

## 6.4 Solutions View - Descriptions

### 6.4.1 Solution Plot

Displays a polar plot with an error ellipse of the current and backup solution (where available):



*Solutions Plot*

The scale of the polar plot can also be changed using the scale slider. Scales range from 50cm to 10m. The Solution Plot view centres on the active solution and the error ellipse for the backup solution is displayed relative to the active solution. Solution error ellipses can be selected using the solution slider.

### 6.4.2 Solution Difference


Displays delta values (dEast and dNorth) of the backup solutions relative to the primary solution. Large delta values indicate that the active or backup solution is not accurate and requires investigation.

Solution Difference		
	dEast	dNorth
Apex PRO	ref	ref
Ultra	-0.11	-0.01
Standard	0.10	-0.34

*Solution Difference*

### 6.4.3 Solution Status


Displays the status of the active and backup solution:



*Solution Status view - PPP*

For PPP solutions, this view shows the number of GNSS satellites used (detailed by GNSS constellation). Green bars indicate how many satellites from each GNSS constellation are used. Amber values indicate satellites that are rejected or uncorrected and therefore not used in the solution. The current solution DOP values (HDOP, PDOP and VDOP) of the selected solution is displayed.

For Veripos Standard solutions, the number of reference stations used is displayed in green:




*Solution Status view – Standard*

#### 6.4.4 UKOOA Statistics (Quantum Survey only)

Displays the following statistical information:

- F-Test status
- W-Test status
- MDE value
- Semi-major value

Choose to display either the active or a backup solution information using the tick-boxes. The error ellipse for the selected solution will also be displayed, where the scale can be adjusted:



*UKOOA Statistics view*




#### NOTE

The UKOOA statistics view is only available when Quantum is enabled with a Survey license.

### 6.4.5 2d-SD Time Series


Displays a graph (which is auto-scaled) of the active solution 2d-SD (horizontal standard deviation) value for the last 10 minutes. The 2d-SD values shown are at  $2\sigma$  (95%) confidence.



*2d-SD – Time Series view*

### 6.4.6 Secondary Position

Displays the solution, current 2d-SD (horizontal standard deviation) value, number of satellites used in the calculation and the HDOP.




Secondary Position	
Solution	Apex
2D-SD	0.282m
Satellites Used	16
HDOP	1.35

*Secondary Position view*

## 6.5 Heading and INS View - Descriptions

Heading views are unavailable unless the Quantum Heading feature is activated. Please refer to section [Quantum - Software licenses](#) for further details.

### 6.5.1 Heading




*Heading view*

This view graphically displays vessel heading, vessel trail and Course over Ground (CoG) with numerical values for heading, COG and speed over ground (SOG) are also shown in the top right.


- **Heading (HDG)** refers to the direction in which a vessel's bow (front) points relative to the Earth's reference frame, measured in degrees clockwise from true north. HDG is crucial for navigational assistance, course-plotting, and determining the vessel's orientation in relation to its intended destination or other vessels in the vicinity.
- **Course Over Ground (COG)** refers to the actual direction in which a vessel is moving relative to the Earth's surface, regardless of its heading, as influenced by factors such as the vessel's heading, current, wind, and other external forces.
- **Speed over Ground (SOG)** represents the actual speed, measured in knots, of vessel movement relative to the Earth's surface as determined by combining the vessel's speed through the water while influenced by the effect of external forces such as currents or tides.

The heading value is additionally indicated by a small rectangle (same colour as the vessel shape) on marked on the graticule. A brown arrow indicates the course:



*Heading and COG indicators*


This view also displays the vessel track plots (if enabled). The scale of the view may need to be adjusted to allow the vessel track plot to be visible:



*Vessel track plot view*



The vessel shape shown on the graphical views can be either a generic ship or generic rig as configured in the [Settings - Display](#) section:



*Heading views – Ship shape (left), Rig shape (right)*

### 6.5.2 Heading Data

Displays the Heading (**HDG**), Course (**COG**) and Speed (**SOG**) and the heading standard deviation (**SD**). A lower heading SD indicates a more accurate heading solution.

Heading Data			
HDG	152°		
COG	150.8°		
SOG	28.1 knots		
SD	0.4°		


*Heading Data*

### 6.5.3 Surge and Sway

Provides an indication of vessel Forward/Aft (Surge) and Port/Starboard (Sway) movement in terms of direction and speed.

Blue direction arrows indicate movement in that direction (in relation to vessel North). The direction arrows also show the speed (knots) in which the vessel is moving in each axis.

Overall vessel heading, CoG, SOG and vessel heading SD are also displayed:



*Surge and Sway view*




#### NOTE

The layout of the Surge and Sway view will vary depending on the tile size it is placed in.


### 6.5.4 INS Data

LD900 and LD900M models licensed for INS can use the INS Heading Data view. Once INS has been interfaced and configured, this view will populate with INS Heading, Pitch, Roll, Heave and Status (Good, Aligned, INS Aligning, High Variance or Error) values.



### 6.5.5 Heave

The Heave tile plots the vessel heave (metres) on a time series plot. Heave is the short term vertical displacement of a vessel relative to the mean of the sea state caused by wave or swells.



## 6.6 Interference and Spoofing View - Descriptions

Quantum has a licensed capability of enabling digital RF filters to protect (by approximately 30 dBs) the LD8 or LD900 positioning computation against RF interference. An active Interference Mitigation license is required to configure and apply Interference Mitigation, without which the configuration options will not be visible. See the Quantum [Software licenses](#) section for more information.




### NOTE

Without an active Interference Mitigation license, users can still access RF spectrum monitoring and spoofing detection functions.

### 6.6.1 Spoofing Status

To display information relating to spoofing status, spoofing must first be activated and calibrated in **Settings > System Configuration > Receiver Management**. Will display 'Spoofing is not calibrated' until calibration/activation.



Spoofing detection requires calibration. Without calibration the spoofing detect function is not active.


Calibration will remain 'Uncalibrated' until Start Calibration is initiated in Settings and the calibration is successfully completed. Once **Start Calibration** is activated, Calibration will switch to 'Calibrating' and then to 'Passed' once it is complete.

A Calibration status of 'Failed' will indicate that calibration has not been successful and that it must be re-attempted.

Upon successful spoofing detection calibration, the Calibration status will change to **Passed** and **Last Calibration** will display the UTC date and time of the successful calibration.

### 6.6.2 Interference Status


Displays the high-level interference status. If interference is detected, the GNSS frequency band and the centre frequency (Mhz) of the interference will be indicated.



*Interference Status tile with an L2 interference example*

### 6.6.3 RF Spectrum

The **RF Spectrum** view monitors and identifies any potential interference source. The Spectrum view can determine an interfering signal's centre frequency, bandwidth, amplitude, and the GNSS signal bands potentially subject to impact (L1, L2, L5 and L-band signal bands). The initial view shows the GPS L1 spectrum. The example below highlights a settings cog icon in the top right, which provides RF Spectrum and HDR Mode configuration options.



*RF Spectrum view with Frequency (MHz) on X axis and Power dBm on Y axis.*


### 6.6.3.1 RF Spectrum tab

Clicking on the RF Spectrum settings icon will open the Configure RF Spectrum window, allowing users to select particular frequencies (**L1**, **L2**, **L5** and **L-BAND**), which will change the RF Spectrum view accordingly, allowing for the monitoring of received signals used by different GNSS systems and their associated signal type.

To focus on a particular area of the radio spectrum, the user first selects **WIDE BAND** (pre-selected), **PASS BAND** or **FILTER BAND** (the filter band is only visible when an ITK license is enabled).



Clicking upon **PASS BAND** presents an option to toggle between specific frequency signals such as, in the case of the L1 frequency, 'GPSL1', 'GLONASSL1', 'BEIDOUB1I', 'BEIDOUB1C' and 'GALILEOE1'.




As detailed in the next section, a filter must be defined and active to select the **FILTER BAND** view.

### 6.6.3.2 Filters tab


With an active ITK software license option, Quantum can configure and apply digital RF filters (a maximum of two filters) within the interfaced LD8 or LD900 receiver. These software filters can provide up to 30 dBs of protection from unwanted RF signals.

To illustrate the use of filters, consider an example scenario of an interfering signal at carrier 1582.5 MHz with a 100 KHz bandwidth. Initially, the user can observe interference within the RF Spectrum Pass Band - GPS L1 view. The spectrum view allows the user to estimate the centre frequency of the interfering carrier and to estimate the interference power:



*Interference identified within the RF Spectrum Pass Band - GPS L1 view*


The spectrum view lets the user estimate the interfering carrier's centre frequency and interference power. A logical first step would be to enable [HDR Mode](#) for the L1 signal band:




The user selects the filters tab and adds a notch filter at 1582.5 MHz with a 1Mhz bandwidth. Shown below are the filter configuration options, with the chosen values highlighted. Parameters are set and applied:



The red and green graphic at the bottom of the filter configuration window illustrates the frequency of the notch filter (red) and the mirrored filter, which is a byproduct. The green section denotes the part of the spectrum reserved for the signal; in this example, GPS L1 centred on 1575.42 MHz:




The spectrum view now displays an active GPS L1 Notch filter:






Selecting the filter band view allows observation of the effectiveness of the GPS L1 filter. This view is only available once a filter is active:



The GPS L1 filter view:



The notch filter is visible, with a second notch filter created as an automatic byproduct of the software filtering. The interference peak is still visible but suppressed. With the GPS L1 notch filter active, we can note the GPS L1 SNR values return to normal and stable signal strengths.



### 6.6.3.3 HDR Mode tab

Selecting the HDR Mode tab provides the ability to enable HDR (High Dynamic Range) Mode on **L1**, **L2**, **L5**, **Primary L-band** and **Secondary L-band** frequency bands. HDR mode assists with signal tracking when signal strength is low or interference is present. If any signal tracking issues occur (interference, low or no signal tracking), enabling HDR Mode will help restore signal tracking.


## 6.7 Tides View – Descriptions

Tides views are not available unless the Quantum Tides feature is activated with the Quantum Software license. Please refer to section [Quantum - Software licenses](#) for further details.

### 6.7.1 Tides - GNSS

The **Tides-GNSS** view displays following information:

- **Min Height** - Smallest position height in the last interval
- **Max Height** - Largest position height in the last interval
- **Mean Height** - Mean of the position heights within the last interval
- **Height SD** - SD of the sample heights in the last interval
- **Sample Count** - Percentage of available samples for the current interval




Min Height	650.3
Max Height	650.51
Mean Height	650.45
Height SD	0.06
Sample Count	100%

*Tides GNSS view*

### 6.7.2 Tides - Doodson

The **Tides - Doodson** view displays following information:

- **Mean** - Mean MSS tide is the mean of all tides above MSS estimated by the Doodson filter.
- **Latest** - Latest MSS tide is the tide above MSS estimated by the Doodson filter.
- **Draft** - Calculated as the current Doodson value minus the Doodson value for the first record.



Mean	0.033
Latest	0.033
Draft	0.01

*Tides Doodson view*



**NOTE**

There is a 39 hour initialisation period for Quantum to calculate Tides Doodson values.

### 6.7.3 Tides – Status


The **Tides - Status** view displays following information:

Information	Details
Sample Count	Displayed if sufficient samples during the last interval were used. Green=True (at least 50%) Red=False
Data Gap Identifier	Displayed if a data gap is detected (data gaps are not desired) Green icon=True (attention required) Red icon=False (this is desired status)
Hold off Period	Status showing if the hold-off period is active. Green=True Red=False



*Tides - Status view*


If the Hold-off Period is active (green), then a Hold off countdown bar is displayed. The bar shows the remaining time until the end of the hold-off period is reached:



*Tides Status view – Hold off period active*

#### 6.7.4 Resource Use


Displays the disk space used within the tides folder:



*Tides - Resource Use*

#### 6.7.5 Tides – PPP Height – Time Series

Displays the maximum (green) average (blue) and minimum (red) PPP height values (metres) over time (past 72 hours).




*Tides - PPP Height - Times Series*

## 6.8 System Status View

### 6.8.1 System Status


Displays the status of the hardware platform on which Quantum is operational:



*System Status*

### 6.8.2 PTP Status

Displays PTP status, indicating if PTP mode is enabled and if the receiver is providing GPS time to synchronise clocks on other network equipment.




*PTP Status*

## 7 Troubleshooting

Use this section to assist with any problems encountered when using Quantum. Significant errors will trigger system notifications. These notifications will provide advice on how to troubleshoot the issue.

### Example problem 1

Upon configuring Quantum on a PC to connect to a Veripos receiver, the following message appears:




### Solution

Check the receiver IP address and ensure that the IP address entered in Quantum is correct. Also ensure the correct receiver type is selected during configuration. Check that the Ethernet cable is properly connected between the Veripos receiver and the Quantum PC.

### Example problem 2

When using Quantum, with a software license obtained for existing PC and then attempting to launch Quantum on another PC using the same license, the following message will be displayed:




### Solution

The license code used on the previous PC is still valid, this license must be entered on the new Quantum PC. Go to the **Authorisations** menu on the previous Quantum PC, copy the Quantum software license and then enter the same license on the new PC. If it is not possible to recover the code from the old PC, contact the Veripos Helpdesk who will be able to provide the license code.



### Example problem 3

Quantum is flashing red and none of the display tiles are populated:



### Solution

Check the **Notifications** Tab. Notifications in the **Status** section should provide an insight into why the Quantum system is alarming.

If the Veripos receiver in-use is working normally, check the Ethernet connection to the Quantum PC.

Check the status of the Veripos receiver in-use. If the receiver also shows a loss of position or corrections, check antenna(s) and cabling.

### Example problem 4

Sidebar has an amber border:



### Solution

An amber sidebar indicates a non-critical issue with either the active or backup solution.

If, as shown in the example above, there is a blue spinner displayed next to one of the solutions, this indicates that the solution is currently converging. No action is required; the solution will settle after around 30 minutes.

Other situations can cause an amber sidebar, such as the backup solution being uncorrected, active solution having timed-out and system reverting to the backup solution.

### Example problem 5


A heading input is configured in Quantum, but no heading views can be selected

#### Solution

To display heading information, the Quantum license must include the heading feature. Check the Authorisations page to confirm if there is an active heading license. Contact the Veripos Helpdesk to activate if required.

### Example problem 6

A Veripos receiver is subscribed to the Apex Pro service, but the Quantum display suggests that not all available constellations are being used:



	In Use	Tracked
GPS	10	10
GLONASS	7	7
BeiDou	6	6
Galileo	0	1

#### Solution

Not all constellations are available at all locations. The Apex5 solution utilises a number of GNSS constellations. The solution actively adds or remove constellations as they become available or unavailable.

## 8 Reference information

### 8.1 Tides formats

#### 8.1.1 Tideinfo file format

##### Tideinfo file format description

The TideInfo.txt file contains current system height and tide information at the Averaging Period as configured by the user. This file contains comma delimited strings with variable length fields. Null fields indicate that no information is currently available; they should not be interpreted as 'zero'. A checksum is included for extra robustness. Negative tide is low tide and positive tide is high tide respectively.

##### Tideinfo sentence structure & example

\$UltraTide,20070228,21:40:00,28,600,600,5236.2830,N,00143.5184,E,5.74,0.08,0.07,5.66,5.82,5.45,0.29,0.02,5.72,44.84,0.00,0.27,EGM96\*2B

##### Tideinfo sentence defined

Content	Format	Unit	Notes
0	TalkerID	[-]	\$UltraTide or \$ApexTide (dependent on active PPP calculation)
1	yyyymmdd	[-]	Identifies year, month and day for which all information in the string is valid.
		hh:mm:ss (UTC)	
2	Time (UTC or GPS)	or ssssssssss (GPS)	Identifies time in UTC or GPS for which all information in the string is valid.
3	Sequence Number	numerical	Sequential number incrementing by 1 for each averaging period. Maximum is 99999999 after which an automatic reset back to 1 takes place.
4	Averaging Period	numerical	User selected period over which Veripos Apex or Ultra heights are averaged in seconds. Minimum is 60, maximum is 3600.
5	Sample Count	numerical	Represents the total number of Veripos Apex or Ultra PPP height samples collected during the averaging period, which are used to calculate the average PPP height. A minimum of 50% of the defined 'Averaging Period' is required to produce a valid sample count. This count remains constant throughout each epoch, updating only at the end of each new averaging period.
6	Latitude	ddmm.mmmm (degrees, minutes and	Location where height and tide information is valid.

Content	Format	Unit	Notes
		decimal minutes)	
7	Latitude Hemisphere	c	N or S
8	Longitude	ddmm.mmmm (degrees, minutes and decimal minutes)	Location where height and tide information is valid.
9	Longitude Hemisphere	c	E or W
10	Mean Height	hh.hh (metres)	Mean of the Veripos Apex or Ultra heights during the 'Averaging Period'
11	Mean of Height SD	hh.hh (metres)	Mean of the Height SD's associated with the Veripos Apex or Ultra heights during the 'Averaging Period'. This is an indication of the quality of the Veripos Apex or Ultra heights
12	SD of Heights	hh.hh (metres)	Standard deviation of the Veripos Apex or Ultra heights during the 'Averaging Period'. This is an indication if the variation of the height due to vessel motion and position quality.
13	Minimum of Heights	hh.hh (metres)	Minimum of the Veripos Apex or Ultra heights during the 'Averaging Period'
14	Maximum of Heights	hh.hh (metres)	Maximum of the Veripos Apex or Ultra heights during the 'Averaging Period'
15	Doodson	hh.hh (metres)	Estimated antenna height above Mean Sea Surface from the Doodson filter. First available after 39 hours.
16	MSS Tide	hh.hh (metres)	Local tide based on the Mean Sea Surface derived from the Doodson filter. First available after 39 hours.
17	Geoid Tide	hh.hh (metres)	Local tide relative to user selected Geoid (see field 22). Available instantaneously after 'hold-off' time
18	Antenna Height	hh.hh (metres)	User entered height of the antenna above the waterline.
19	Geoid Separation	hh.hh (metres)	Local offset between the user selected Geoid and the WGS84 reference ellipsoid.
20	Draft	hh.hh (metres)	The draft. Calculated as the current Doodson value minus the Doodson value for the first record.
21	Vertical Bias	hh.hh (metres)	The vertical bias detected between MSS Tide and Geoid Tide. Calculated as Antenna Height minus Doodson plus Draft.

Content	Format	Unit	Notes
22	Geoid Model	-	EGM96, EGM08 or USER

### 8.1.2 Sprint\_Tides file format

#### Sprint\_Tides file format description

The SPRINT\_Tides.txt file contains the current UltraTide with the opposite sign compared to the MSS Tide contained in the TideInfo.txt and Doodson.txt files. This file contains comma delimited strings with variable length fields. Null fields indicate that no information is currently available; they should not be interpreted as 'zero'. A checksum is included for extra robustness. Negative tide is high tide and positive tide is low tide respectively.

#### Sprint\_Tides sentence structure & example

12,20,22,09,2006,-0.88

#### Sprint\_Tides sentence defined

Content	Format	Unit	Notes
0	Hours	HH	Hours in the day (UTC). Time for which all information in the string is valid.
1	Minutes	MM	Minutes in the day (UTC). Time for which all information in the string is valid.
2	Day	DD	Day in the month.
3	Month	MM	Month in the year.
4	Year	YYYY	Year.
5	UltraTide	hh.hh (metres)	Local UltraTide based on the Mean Sea Surface derived from the Doodson filter. First available after 39 hours. Set as 99999.99 when no UltraTide value is available.
	*	c	Fixed end delimiter (real time output only)
		cc	Checksum (real time output only)

## 8.2 Heading formats

### 8.2.1 HDT heading string format

Quantum allows for input of [external heading sources](#) for display purposes, using the NMEA HDT sentence format.

#### HDT sentence structure & example

```
$GNHDT dd.dddd, T hh
$GNHDT 75.5664, T *36
```

#### HDT sentence defined

Field	Content
HDT	Heading (true) message
dd.dddd	Heading in degrees
T	Degrees True
*hh	Checksum

### 8.2.2 THS heading string format

Quantum allows for input of [external heading sources](#) for display purposes, using the NMEA THS sentence format.

#### THS sentence structure & example

```
$GNTHS dd.dd, T *hh
$GNTHS 125.5, T *2F
```

#### THS sentence defined

Field	Content
THS	True heading speed message
dd.dd	Heading in degrees
T	Degrees True
*hh	Checksum

## 8.3 Alert management sentence formats

### 8.3.1 ALC cyclic alert list string format

Quantum transmits alert status updates using an ALC sentence format.

#### ALC sentence structure with no active alerts

```
$GNALC aa bb null c *hh
$GNALC, 01, 01, , 0 *77
```

#### ALC sentence structure with one active alert

```
$GNALC aa bb null c DDD eeeee null f *hh
$GNALC, 01, 01, , 1, HGN, 100001, , 1 *06
```

#### ALC sentence structure with two active alerts

```
$GNALC aa bb null c DDD eeeee null DDD eeeee null f *hh
$GNALC, 01, 01, , 2, HGN, 100002, , HGN, 100001, , 1 *76
```

#### ALC sentence defined

Field	Content
ALC	Cyclic alert list message
aa	Total number of sentences
bb	Current sentence number
null	Sequential message identifier
c	Number of alert entries (0 = no alerts, 1 = jamming or spoofing present, 2 = jamming and spoofing present)
DDD	Manufacturer mnemonic code (Always HGN)
eeeeee	Numeric identifier of the alert (100001 = Spoofing, 100002 = Jamming)
null	Alert instance number
f	Revision counter for the alert (1 = V, 2 = A)
*hh	Checksum



### 8.3.2 ALF alert sentence string format

Quantum transmits alert status updates using an ALF sentence format.

#### ALF sentence structure with spoofing detected, unacknowledged

```
$GNALF a b null hhmmss.ss, C D E FFF, gggggg, null, h, i, J, *hh
$GNALF, 1, 1, , 091636.00, B, W, V, HGN, 100001, , 1, 0, SPOOFINGDETECT, *4A
```

#### ALF sentence structure with spoofing detected, unacknowledged

```
$GNALF a b null hhmmss.ss, C D E FFF, gggggg, null, h, i, J, *hh
$GNALF, 1, 1, , 102711.70, B, W, A, HGN, 100002, , 2, 0, JAMMINGDETECT, *1B
```

#### ALF sentence structure with jamming detected, cleared

```
$GNALF a b null hhmmss.ss, C D E FFF, gggggg, null, h, i, J, *hh
$GNALF, 1, 1, , 064445.87, B, W, N, HGN, 100002, , 2, 0, JAMMINGDETECT, *1F
```

#### ALF sentence defined

Field	Content
ALF	Alert sentence
a	Total number of sentences
b	Current sentence number
null	Sequential message identifier
hhmmss.ss,	UTC time of the last alert status update
C	Alert category (Always B)
D	Alert priority (Always W)
E	Alert State (A = ACN acknowledged Spoofing/Jamming, N – Nominal, V ACN Unacknowledged Spoofing/Jamming)
FFF	Manufacturer mnemonic code (Always HGN)
gggggg	Numeric identifier of the alert (100001 = Spoofing, 100002 = Jamming)
null	Alert instance number
h	Revision counter for the alert (1 = V, 2 = N or 1 = V, 2 = A, 3 = N)
i	Escalation counter
J	Alert Text (Spoofing = “SPOOFINGDETECT, Jamming = “JAMMINGDETECT”)
*hh	Checksum

### 8.3.3 ACN alert command string format

Quantum supports alert control input via an ACN sentence format and provides systems a means to acknowledge or request a repeat of alert details.

#### ACN sentence structure, acknowledge spoofing alert example

```
$IACN hhmmss.ss, AAA, AlertID, null, Command, StatusFlag *hh
$IACN 112524.01, CAM, 100001, , A, C *28
```

#### ACN sentence structure, retransmit jamming example

```
$IACN hhmmss.ss, AAA, AlertID, null, Command, StatusFlag *hh
$IACN 143623.15, CAM, 100002, , Q, C *3E
```

#### ACN sentence defined

Field	Content
ACN	Alert command
hhmmss.ss	UTC time of the alert condition (Can be null)
AAA	Manufacturer mnemonic code
AlertID	Numeric identifier of the alert (100001 = Spoofing, 100002 = Jamming)
Instance	Alert instance number
Command	Command type (Quantum expects A = Acknowledge or Q = Query)
StatusFlag	Sentence status flag (Always 'C' = Command issued)
*hh	Checksum

## 9 Contact information

All initial contacts regarding technical or support issues should be initially addressed to Veripos Support. Where appropriate Support will refer issues to the regional operations and engineering teams.

### 9.1 Veripos Support details

<b>Veripos Support website</b>	<a href="https://veripos.com/support">https://veripos.com/support</a>
<b>Veripos Support telephone</b>	+44 1224 965900
<b>Veripos Support e-mail</b>	<a href="mailto:support.veripos@hexagon.com">support.veripos@hexagon.com</a>

## 10 Appendix

### 10.1 Veripos PPP station ID's

Service	Station ID	NMEA station ID
Ultra	68	0068
Ultra2	68 + 75	0268
Apex	81	0081
Apex2	81 + 82	0281
Apex5 / Apex Pro	81 + 82 + 91 + 92 + 62	0481*

\*When Apex Pro solution uses less than four GNSS constellations, the NMEA station ID will change according to the number of constellations in-use e.g. 0381 if three constellations are in-use.

### 10.2 Veripos reference stations

The latest Veripos station listing can be found on the [Veripos support website](#).

### 10.3 L-band coverage map

